Air/water heat pump NIBE F2040 *6, 8, 12, 16*







Table of Contents

1	Important information	_ 4		Filling and venting	_ 42
	Safety information	4		Compressor heater	_ 42
	Symbols	4		Start-up and inspection	_ 43
	Marking	4		Readjusting, heating medium side	_ 44
	Serial number	_ 4		Adjustment, charge flow	_ 44
	Recovery	_ 5			
	Environmental information	. 5	7	Control	
	Inspection of the installation	. 6		Menu 5.11.1.1 – Heat pump EB101	_ 45
	Compatible indoor modules (VVM) and control modules (SMO)	. 7	8	Disturbances in comfort	
	Indoor modules	. 7		Troubleshooting	_ 46
	Control modules	_ 7	9	Alarm list	_ 54
2	Delivery and handling Transport and storage		10	Accessories	_ 57
	Assembly		4.4	T 1	
	Supplied components		11	Teermiear data	
	Removing the covers			Dimensions and setting-out coordinates	
	Removing the front panel			Sound pressure levels	
	Removing the side panel			Technical specifications	
				Working area Capacity and COP	
3	The heat pump design	14			_ 00
	General	14		Output with lower fuse rating than recommended	_ 68
	Electrical connection	22		Energy labelling	
4	Pipe connections	26		Electrical circuit diagram	
	General	26	ltc	em register	_ 83
	Pipe coupling heating medium circuit	26	710	THI TOGISTOI	_ 00
	Pressure drop diagram	_ 27	Cc	ontact information	_ 87
	Pipe connections flex hose	_ 27			
	Docking alternatives	_ 28			
5	Electrical connections	29			
	General	_ 29			
		30			
	Connections	_ 32			
6	Commissioning and adjusting				
	Preparations	_ 42			

NIBE F2040 Table of Contents

1 Important information

Safety information

This manual describes installation and service procedures for implementation by specialists.

The manual must be left with the customer.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Rights to make any design or technical modifications are reserved.

©NIBE 2018.

Symbols



NOTE

This symbol indicates danger to person or machine .



Caution

This symbol indicates important information about what you should consider when installing or servicing the installation.



TIP

This symbol indicates tips on how to facilitate using the product.

Marking

The CE mark is obligatory for most products sold in the EU, regardless of where they are made.

IP24 Classification of enclosure of electro-technical equipment.




Danger to person or machine.



Read the User Manual.

Serial number

The serial number for F2040 can be found on the side of the foot.





Caution

You need the product's (14 digit) serial number for servicing and support.

Recovery



Leave the disposal of the packaging to the installer who installed the product or to special waste stations.

Do not dispose of used products with normal household waste. It must be disposed of at a special waste station or dealer who provides this type of service.

Improper disposal of the product by the user results in administrative penalties in accordance with current legislation.

Environmental information

This unit contains a fluorinated greenhouse gas that is covered by the Kyoto agreement.

The equipment contains R410A, a fluorinated greenhouse gas with a GWP value (Global Warming Potential) of 2088. Do not release R410A into the atmosphere.

Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. Fill in the page for information about installation data in the User manual.

~	Description	Notes	Signature	Date
Heating medium (page 26)				
	System flushed			
	System vented			
	Particle filter			
	Shut-off and drain valve			
	Charge flow set			
Elec	tricity (page 29)			
	Fuses property			
	Safety breaker			
	Earth circuit-breaker			
	Heating cable type/effect			
	Fuse size, heating cable (F3)			
	Communication cable connected			
	F2040 addressed (only when cascade connection)			
	Connections			
	Main voltage			
	Phase voltage			
	When installing F2040-6, check that the software version of the indoor module/control module is at least v8320.			
Mis	cellaneous			

Compatible indoor modules (VVM) and control modules (SMO)

	VVM 310	VVM 320	VVM 500	SMO 20	SMO 40
F2040-6	X	X	X	X	X
F2040-8	X	X	X	X	X
F2040-12	X	X	X	X	X
F2040-16	X		X	Χ	X

Indoor modules

Control modules

VVM 310 VVM 310

Part no. 069 430 With integrated EMK 310

Part no. 069 084

SMO 20

Control module Part no. 067 224

SMO 40

VVM 320 VVM 320

Stainless steel, 1x230 V Stainless steel, 3x230 V

Part no. 069 111 Part no. 069 113

Control module Part no. 067 225

VVM 320 VVM 320

Enamel, 3x400 V Stainless steel, 3x400 V

With integrated EMK 300

Part no. 069 203

Part no. 069 109

VVM 320 VVM 500

Copper, 3x400 V Part no. 069 108

×400 V Part no. 069 400


2 Delivery and handling

Transport and storage


F2040 must be transported and stored vertically.

Assembly

- Place F2040 outdoors on a solid level base that can take the weight, preferably a concrete foundation. If concrete slabs are used they must rest on asphalt or shingle.
- The concrete foundation or slabs must be positioned so that the lower edge of the evaporator is at the level of the average local snow depth, although a minimum of 300 mm.
- The F2040 should not be positioned next to sensitive walls, for example, next to a bedroom.
- Also ensure that the placement does not inconvenience the neighbours.
- F2040 must not be placed so that recirculation of the outdoor air can occur. This causes lower output and impaired efficiency.
- The evaporator should be sheltered from direct wind, which negatively affects the defrosting function. Place F2040 protected from wind against the evaporator.
- Large amounts of condensation water, as well as melt water from defrosting, may be produced. Condensation water must be led off to a drain or similar (see page 9.
- Care must be exercised so that the heat pump is not scratched during installation.




Do not place F2040 directly on the lawn or other non solid surface.



If there is a risk of snow slip from roof, a protective roof or cover must be erected to protect the heat pump, pipes and wiring.

INSTALLATION AREA

The distance between F2040 and the house wall must be at least 150 mm. Clearance in front of F2040 should be at least one metre.



CONDENSATION WATER TROUGH

The condensation water trough collects and leads away most of the condensation water from the heat pump.



NOTE

It is important to the heat pump function that condensation water is led away and that the drain for the condensation water run off is not positioned so that it can cause damage to the house.

Condensation runoff should be checked regularly, especially during the autumn. Clean if necessary.



NOTE

Pipe with heating cable for draining the condensation water trough is not included.

To ensure this function the accessory KVR 10 should be used.




NOTE

The electrical installation and wiring must be carried out under the supervision of an authorised electrician.

- The condensation water (up to 50 litres/24 hrs) that collects in the trough should be routed away by a pipe to an appropriate drain, it is recommended that the shortest outdoor stretch possible is used.
- The section of the pipe that can be affected by frost must be heated by the heating cable to prevent freezing.
- Route the pipe downward from F2040.
- The outlet of the condensation water pipe must be at a depth that is frost free or alternatively indoors (with reservation for local ordinances and regulations).
- Use a water trap for installations where air circulation may occur in the condensation water pipe.
- The insulation must seal against the bottom of the condensation water trough.

Recommended alternative for leading off condensation water


Stone caisson



If the house has a cellar the stone caisson must be positioned so that condensation water does not affect the house. Otherwise the stone caisson can be positioned directly under the heat pump.

The outlet of the condensation water pipe must be at frost free depth.

Drain indoors




The condensation water is lead to an indoor drain (subject to local rules and regulations).

Route the pipe downward from F2040.

The condensation water pipe must have a water seal to prevent air circulation in the pipe.

KVR 10 spliced as illustrated. Pipe routing inside house not included.

Gutter drainage



The outlet of the condensation water pipe must be at frost free depth.

Route the pipe downward from F2040.


The condensation water pipe must have a water seal to prevent air circulation in the pipe.



Caution


If none of the recommended alternatives is used good lead off of condensation water must be assured.


Supplied components



Removing the covers









F2040-16









Removing the front panel


F2040-6




F2040-8



F2040-12




F2040-16




Removing the side panel

F2040-12





F2040-16





3 The heat pump design


General

















F2040-16







LIST OF COMPONENTS F2040

Pipe connections

QM36 Shut-off valve, liquid side QM37 Shut-off valve, gas side

XL1 Connection, heating medium out from F2040,

G1" (Ø28 mm)

XL2 Connection, heating medium in to F2040,

G1" (Ø28 mm)

Sensors etc.

BP1 (63H1) High pressure pressostat

BT3 Temperature sensor, heating medium return

line

BT12 Temperature sensor, condenser supply line

BT14 (Tho- Temperature sensor, hot gas

D)

BT15 Temperature sensor, fluid pipe BT16 (Tho- Temperature sensor 1, evaporator

R1)

BT17 (Tho- Temperature sensor, suction gas

5)

BT28 (Tho- Temperature sensor, ambient

A)

BP2 (LPT) Low pressure transmitter BP4 High pressure sensor

Tho-R2 Temperature sensor 2, evaporator

Electrical components

AA23 Communication board

AA23-F3 Fuse for external heating cable (250 mA), max

45 W.

AA23-S3 DIP switch, addressing of outdoor unit

AA23-X1 Terminal block, KVR

AA23-X4 Terminal block, communication from indoor

module

AA23-X100 Communication with TB EB10 (CH) Compressor heater EB11 (DH) Drip tray heater

F Main fuse compressor unit

GQ1 (FM01) Fan GQ2 (FM02) Fan

(PWB1) Control board (PWB2) Inverter board (PWB3) Filter board

RF2 EMC filter for inverter

RF3 EMC filter for incoming supply

(TB) Terminal block, incoming supply and communic-

ation with board AA23

Cooling components

QN2 (20S) 4-way valve GQ10 (CM) Compressor

QN3 (SM1) Expansion valve, cooling QN1 (SM2) Expansion valve, heating

EP1 Evaporator (copper pipe with aluminium flange)

EP2 Condenser HS1 Drying filter

Miscellaneous

PF1 Type plate
PF3 Serial number


UB1 Cable gland, incoming supply
UB2 Cable grommet, communication
UB3 Cable gland, heating cable (EB14)


W1 Cable, incoming supply


Designations at component positions according to standard EN 81346-


Designations within brackets according to the supplier's standard.


Electrical connection











Electrical components

AA23 Communication board

AA23-F3 Fuse for external heating cable (250 mA), max

45 W.

AA23-S3 DIP switch, addressing of outdoor unit

AA23-X1 Terminal block, KVR

AA23-X4 Terminal block, communication from indoor

module

AA23-X100 Communication with TB EB10 (CH) Compressor heater EB11 (DH) Drip tray heater

F Main fuse compressor unit

GQ1 (FM01) Fan GQ2 (FM02) Fan

(PWB1) Control board(PWB2) Inverter board(PWB3) Filter board

RF2 EMC filter for inverter

RF3 EMC filter for incoming supply

(TB) Terminal block, incoming supply and communic-

ation with board AA23

Designations at component positions according to standard EN 81346-2

Designations within brackets according to the supplier's standard.

4 Pipe connections

General

Pipe installation must be carried out in accordance with current norms and directives.

F2040 can only operate up to a return temperature of about 55 °C and an outgoing temperature of about 58 °C from the heat pump.

F2040 is not equipped with external shut off valves on the water side; these must be installed to facilitate any future servicing. The return temperature is limited by the return line sensor.

WATER VOLUMES

When docking with F2040 free flow in the climate system is recommended for correct heat transfer. This can be achieved by use of a bypass valve. If free flow cannot be ensured, it is recommended that a buffer tank (NIBE UKV) is installed.

Following water volumes are recommended

F2040	-6	-8	-12	-16
Minimum volume, climate system during heating/cooling	20	50	80	150
Minimum volume, climate system during under floor cooling	50 I	80	100 I	150 l

\j\

NOTE

The pipe work must be flushed before the heat pump is connected, so that any contaminants do not damage the components.

Pipe coupling heating medium circuit

- The heat pump must be vented by the upper connection (XL1) using the venting nipple on the enclosed flexible hose.
- Install the enclosed particle filter before the inlet, i.e. the lower connection (XL2) on F2040.


- All outdoor pipes must be thermally insulated with at least 19 mm thick pipe insulation.
- Install shutoff and drain valves so that F2040 can be emptied in the event of prolonged power failures.
- The supplied flexible hoses act as vibration dampers.
 The flexible pipes are fitted so an elbow is created, thus acting as vibration damping.


CHARGE PUMP

The charge pump (not included in the product) is powered and controlled from the indoor module/control module. It has a built-in anti-freezing function and must therefore not be switched off when there is a risk of freezing.


At temperatures below +2 °C the charge pump runs periodically, to prevent the water from freezing in the charge circuit. The function also protects against excess temperatures in the charge circuit.

Pressure drop diagram





Pipe connections flex hose



Docking alternatives

F2040 can be installed with indoor module (VVM) or control module (SMO). The required safety equipment must be installed in accordance with current regulations for all docking options.

The safety equipment must be installed in accordance with current regulations for all docking options.

See nibe.eu for more docking options.

CONNECTING ACCESSORIES

Instructions for connecting accessories are in the installation instructions provided for the respective accessory. See page 57 for the list of the accessories that can be used with F2040.

5 Electrical connections

General

- The heat pump must not be connected without the permission of the electricity supplier and must be connected under the supervision of a qualified electrician.
- If a miniature circuit-breaker is used, this must have motor characteristic "C" (compressor operation). For MCB size, see "Technical specifications".
- F2040 does not include an omnipolar circuit breaker on the incoming power supply. The heat pump's supply cable (W1) must therefore be connected to a circuit breaker with a breaking gap of at least 3 mm. If the building is equipped with a residual current device, the heat pump should be equipped with a separate one. The residual current device should have a nominal tripping current of no more than 30 mA. Incoming supply must be 230 V 50Hz via electrical distribution units with fuses.
- If an insulation test is to be carried out in the building, disconnect the heat pump.
- Communication cable (W2) is inserted from the rear side through UB2.
- Connect communication cable (W2) from terminal block (AA23-X4) to the indoor module.



NOTE

Electrical installation and any servicing must be carried out under the supervision of a qualified electrician. Disconnect the current with the circuit breaker before carrying out any servicing. Electrical installation and wiring must be carried out in accordance with the national stipulations in force.



NOTE

Check the connections, main voltage and phase voltage before starting the machine to prevent damage to the air/water heat pump's electronics



NOTE

The live external control must be taken into consideration when connecting.




NOTE

If the supply cable is damaged, only NIBE, its service representative or similar authorised person may replace it to prevent any danger and damage.


NIBE F2040 Chapter | 29


F2040-6 F2040-8





30 Chapter | *NIBE F2040*

F2040-16









NIBE F2040 Chapter | 31


Connections




NOTE

To prevent interference, unscreened communication and/or sensor to external connections cables must not be laid closer than 20 cm to high voltage cables when cable routing.


POWER CONNECTION *F2040-6*







32 Chapter | NIBE F2040


F2040-8






F2040-12





NIBE F2040 Chapter | 33



Incoming supply cable (W1) is enclosed and connected to terminal block X1 at the factory. Outside the heat pump there is approx. 1.8 m of cable available.

Connect communication cable (W2) (provided by installer) to terminal block AA23-X4 and secure with two cable ties, see image.


For connection of accessory KVR 10, heating cable (EB14) is connected via cable grommet UB3, see External heating cable KVR 10 (Accessory) on page 36.

LIST OF COMPONENTS


UB1 Cable grommet, cascade connection
UB2 Cable grommet, communication
UB3 Cable grommet, heating cable (EB14)

W1 Cable, incoming supply


34 Chapter | NIBE F2040




F2040-8



F2040-12



NIBE F2040 Chapter | 35



EXTERNAL HEATING CABLE KVR 10 (ACCESSORY)

F2040 is equipped with a plinth for external heating cable EB14 not supplied). The connection is fused with 250 mA (F3 on the communication board AA23). If another cable is to be used, the fuse must be replaced with a suitable one (see table).




NOTE

Self regulating heating cables must not be connected.

Length, heating cable (m)	P _{tot} (W)	Fuse (F3)	Part No.
1	15	T100mA/250V	718 085
3	45	T250mA/250V	518 900*
6	90	T500mA/250V	718 086

^{*}Fitted at the factory.

Connect external heating cable (EB14) to terminal block X1:4–6 according to following image:





NOTE

The pipe must be able to withstand the heat from the heating cable.


To ensure this function the accessory KVR 10 should be used.

36 Chapter | NIBE F2040


Cable routing

The following images show recommended cable routing from the electrical connection to the condensation pipe. Route the heating cable (EB14) through the gland on the underside and secure with two cable ties at the electrical connection. The transition between the electrical cable and the heating cable must occur after the gland to the condensation pipe.


F2040-6




F2040-8



F2040-12



F2040-16




AMBIENT TEMPERATURE SENSOR

An ambient temperature sensor BT28 (Tho-A) is located on the rear of F2040.

NIBE F2040 Chapter | 37

COMMUNICATION INDOOR MODULE

F2040 can communicate with NIBE indoor modules, by connecting the indoor module to the terminal block X4:1–3 according to the following image:





NOTE

When installing F2040-6, the NIBE indoor module must have the correct software version. Please ensure that the indoor module, in this case, has at least software version v8320.

For connection of indoor module, see relevant manual on nibe.eu.

38 Chapter | NIBE F2040

CONNECTION BETWEEN F2040 AND CONTROL MODULE




NOTE

When installing F2040-6, the NIBE control module must have the correct software version. Please ensure that the control module, in this case, has at least software version v8320.

SMO 20


The cable between the units must be connected between terminal block for communication (AA23-X4:1, 2, 3) in F2040 and terminal block for communication (X2-19(A), -20 (B), -21 (GND)) in SMO 20.

Stripped length of conductor is 6 mm.



SMO 20 and F2040

F2040 can communicate with the control module (SMO 20), by connecting to the terminal block in SMO 20, X2-19(A), -20 (B), -21 (GND), according to the following image:




NIBE F2040 Chapter | 39

SMO 40


The cable between the units must be connected between terminal block for communication (AA23-X4:1, 2, 3) in F2040 and terminal block for communication (AA5:X4-1(A), -2 (B), -3 (GND)) in SMO 40.

Stripped length of conductor is 6 mm.



SMO 40 and more F2040

F2040 (one or more) can communicate with the control module (SMO 40), by connecting to the terminal block in SMO 40, AA5:X4-1(A), -2 (B), -3 (GND), according to the following image:



40 Chapter | NIBE F2040

ADDRESSING VIA CASCADE CONNECTION

On the communication board (AA23-S3), the communication address is selected for F2040 to the control module. The default address for F2040 is **1**. In a cascade connection, all F2040 must have a unique address. The address is coded in binary.

Address	S3:1	S3:2	S3:3
1	OFF	OFF	OFF
2	On	OFF	OFF
3	OFF	On	OFF
4	On	On	OFF
5	OFF	OFF	On
6	On	OFF	On
7	OFF	On	On
8	On	On	On

NIBE F2040 Chapter | 41

6 Commissioning and adjusting


Preparations

- Before commissioning, check that the charge circuit and climate system are filled and well vented.
- Check the pipe system for leaks.

Filling and venting

Filling and venting the heating medium system.

- 1. The heating medium system is filled with water to the required pressure.
- 2. Vent the system using the venting nipple (QM20) on the enclosed flexible hose and possibly the circulation pump.



Compressor heater

F2040 (does not apply to F2040-6) is equipped with a compressor heater that heats the compressor before start-up and when the compressor is cold.



NOTE

The compressor heater must have been connected for 6 – 8 hours before the first start, see the section "Start-up and inspection" in the Installer Manual for the indoor section

Start-up and inspection

- The compressor heater (CH) must have been operational for at least 6 8 hours before the compressor start can be initiated. This is done by switching on the control voltage and disconnecting the communication cable.
- 2. F2040 must be addressed if it is to have another address than 1. See chapter Addressing via cascade connection, on page 41.
- 3. The communication cable on the terminal block AA23-X4 must not be connected.
- 4. Turn the isolator switch on.
- 5. Ensure that the F2040 is connected to the power source.
- 6. After 6 8 hours, connect the communication cable (W2) to the terminal block AA23-X4.
- 7. Restart the indoor module. Follow the instructions for "Start-up and inspection" in the installation manual for the indoor module.

The heat pump starts 30 minutes after the outdoor unit has been powered up and the communication cable (W2) has been connected, if necessary.

If scheduled *silent operation* is required, it must be scheduled in the inner section or control unit.



Caution


Silent mode should only be scheduled periodically because the maximum output is limited to approx. the nominal values.




Caution

Do not start any electrical work until at least two minutes after cutting the power.

F2040-6, -8



F2040-12, -16



Readjusting, heating medium side

Air is initially released from the hot water and venting may be necessary. If bubbling sounds can be heard from the heat pump, the circulation pump and radiators the entire system will require further venting. When the system is stable (correct pressure and all air eliminated) the automatic heating control system can be set as required.

Adjustment, charge flow

Instructions for adjusting hot water charging are in the Installer Manual for the relevant indoor module. See page 57 for the list of the indoor units and accessories that can be connected to F2040.

7 Control

Menu 5.11.1.1 – Heat pump EB101

These settings are made on the display in the indoor module.

Cooling permitted

Here you can set whether the cooling function is to be activated for the heat pump.

Silent mode permitted

Set whether silent mode is to be activated for the heat pump here.

Current limit

Set whether the current limiting function is to be activated for the heat pump here. During active function you can limit the value of the maximum current.

Setting range: 6 – 32 A Factory setting: 32 A

Stop temperature compressor

Here you can limit the value for set outdoor temperature down to the value the heat pump is to work.

Setting range -20 - -2 °C

Factory setting -20 °C

blockFreq 1

Select a frequency range within which the heat pump may work here.

blockFreq 2

Select a frequency range within which the heat pump may work here.

NIBE F2040 Chapter 7 | Control 45

8 Disturbances in comfort

Troubleshooting



NOTE

Work behind covers secured by screws may only be carried out by, or under the supervision of, a qualified installation engineer.



NOTE

As F2040 can be connected to a large number of external units, these should also be checked.



NOTE

In the event of action to rectify malfunctions that require work within screwed hatches the incoming electricity must isolated at the safety switch.



Caution

Alarms are acknowledged on the indoor module / control module (VVM / SMO).

The following tips can be used to rectify comfort disruption:

BASIC ACTIONS

First and foremost

Start by checking any alarm messages in the info menu on the indoor module (VVM) / control module (SMO). Follow the instructions on the display on the indoor module (VVM) / control module (SMO).

F2040 not in operation

F2040 communicates all alarms to the indoor module/control module (VVM / SMO).

- Ensure that the F2040 is connected to the power source and that compressor operation is required.
- Check the indoor module/control module (VVM / SMO). See section "Disturbances in comfort" in the Installer Manual for the indoor module/control module (VVM / SMO).

F2040 does not communicate

- Check that the addressing of F2040 is correct.
- Check that the communication cable is correctly connected and working.

Further possible measures

If any components are disconnected from the power.

Start by checking the following items:

- That the heat pump is running or that the supply cable to F2040 is connected.
- Group and main fuses of the accommodation.
- The heat pump's fuse (F).
- The property's earth circuit breaker.

LOW HOT WATER TEMPERATURE OR A LACK OF HOT WATER



Caution

The hot water is always set on the indoor module (VVM) or the control module (SMO).

This part of the fault-tracing chapter only applies if the heat pump is docked to the hot water heater.

- Large hot water consumption.
 - Wait until the hot water has heated up.
- The hot water settings are adjusted on the display on the indoor module / control module.
 - See the manual for the indoor module or control module.
- Clogged particle filter.
 - Check whether alarm "high condenser out" (162) is an information message. Check and clean the particle filter.

LOW ROOM TEMPERATURE

- Closed thermostats in several rooms.
 - Set the thermostats to max in as many rooms as possible.
- Incorrect settings in indoor module or control module.
 - See the manual for the indoor module / control module (VVM / SMO).
- Incorrect flow across the heat pump.
 - Check whether alarm "high condenser in" (163) or "high condenser out" (162) are info messages. Follow the instructions for adjusting charge flow.

HIGH ROOM TEMPERATURE

- Incorrect settings in indoor module or control module.
 - See the manual for the indoor module or control module.

LARGE AMOUNT OF WATER BELOW F2040

Check that the water drainage via the condensation pipe (KVR 10) is working.

SENSOR PLACEMENT

Sensors etc.

BE1 (CT) Current sensor

BP1 (63H1) High pressure pressostat
BP2 (LPT) Low pressure transmitter
BP4 High pressure sensor

BT3 Temperature sensor, heating medium return

line

BT12 Temperature sensor, condenser supply line

BT14 (Tho-D) Temperature sensor, hot gas
BT15 Temperature sensor, fluid pipe

BT16 (Tho-R1) Temperature sensor, heat exchanger, 1
BT17 (Tho-S) Temperature sensor, suction gas
BT28 (Tho-A) Temperature sensor, ambient

EB10 (CH) Compressor heater
EB11 (DH) Drip tray heater
EP2 Condenser

GQ1 (FM01) Fan

GQ10 (CM) Compressor
HS1 Drying filter
QN1 (EEV) Expansion valve

QN1 (SM2) Expansion valve, heating

QN2 (20S) 4-way valve


QN3 (SM1) Expansion valve, cooling

Tho-R2 Temperature sensor, heat exchanger, 2


Designations at component positions according to standard EN 81346-2.

Designations within brackets according to the supplier's standard.


Connection to board (PWB1) F2040-6




F2040-8



F2040-12 /F2040-16





Connection to board (AA23)




Sensor placement in F2040

Outdoor moduleF2040-6









Data for temperature sensor in F2040-6

Tho-D




Tho-A, R




Data for temperature sensor in F2040-8, -12, -16


Tho-D



Tho-S, Tho-R1, Tho-R2



BT28 (Tho-A)



Data for return line temperature sensor (BT3), condensor supply (BT12) and fluid pipe (BT15)

Temperature (°C)	Resistance (kOhm)	Voltage (VDC)
-40	351.0	3.256
-35	251.6	3.240
-30	182.5	3.218
-25	133.8	3.189
-20	99.22	3.150
-15	74.32	3.105
-10	56.20	3.047
-5	42.89	2.976
0	33.02	2.889
5	25.61	2.789
10	20.02	2.673
15	15.77	2.541
20	12.51	2.399
25	10.00	2.245
30	8.045	2.083
35	6.514	1.916
40	5.306	1.752
45	4.348	1.587
50	3.583	1.426
55	2.968	1.278
60	2.467	1.136
65	2.068	1.007
70	1.739	0.891
75	1.469	0.785
80	1.246	0.691
85	1.061	0.607
90	0.908	0.533
95	0.779	0.469
100	0.672	0.414

9 Alarm list

Alarm	Alarm text on the display	Description	May be due to
3	Sensor fault BT3	Sensor fault, Sensor incoming water in F2040 (BT3).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board AA23 in F2040
12	Sensor fault BT12	Sensor fault, Sensor outgoing water in F2040 (BT12).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board AA23 in F2040
15	Sensor fault BT15	Sensor fault, Sensor fluid pipe in F2040 (BT15).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board AA23 in F2040
162	High condenser out	Too high temperature out from the condens-	Low flow during heating operation
		er. Self-resetting.	Too high set temperatures
163	High condenser in	Too high temperature into the condenser. Self-resetting.	Temperature generated by another heat source
183	Defrosting in progress	Not an alarm, but an operating status.	Set when the heat pump runs the defrost- ing procedure
220	HP alarm	The high pressure switch (63H1) deployed 5 times within 60 minutes or for 60 minutes	Insufficient air circulation or blocked heat exchanger
	Self-r Defrosting in progress Not a HP alarm The h 5 time	continuously.	Open circuit or short circuit on input for high pressure switch (63H1)
			Defective high pressure switch
	er. Se 63 High condenser in Too hi Self-re 83 Defrosting in progress Not ar 20 HP alarm The hi 5 time		Expansion valve not correctly connected
			Service valve closed
			Defective control board in F2040
			Low or no flow during heating operation
			Defective circulation pump
			Defective fuse, F(4A)
221	LP alarm	Too low value on the low pressure sensor 3 times within 60 minutes.	Open circuit or short circuit on input for low pressure sensor
			Defective low pressure sensor
			Defective control board in F2040
			Open circuit or short circuit on input for suction gas sensor (Tho-S)
			Defective suction gas sensor (Tho-S)

54 Chapter 9 | Alarm list NIBE F2040

Alarm	Alarm text on the display	Description	May be due to
223	OU Com. error	Communication between the control board and the communication board is interrupted. There must be 22 volt direct current (DC) at the switch CNW2 on the control board (PWB1).	 Any circuit breakers for F2040 off Incorrect cable routing
224	Fan alarm	Deviations in the fan speed in F2040.	 The fan cannot rotate freely Defective control board in F2040 Defective fan motor Control board in F2040 dirty Fuse (F2) blown
230	Continuously high hot gas	Temperature deviation on the hot gas sensor (Tho-D) twice within 60 minutes or for 60 minutes continuously.	 Sensor does not work (see section "Ambient temperature sensor") Insufficient air circulation or heat exchanger Blocked If the fault persists during cooling, there may be an insufficient amount of refrigerant. Defective control board in F2040
254	Communication error	Communication fault with accessory board	F2040 not poweredFault in the communication cable.
261	High temperature in heat exchanger	Temperature deviation on the heat exchanger sensor (Tho-R1/R2) five times within 60 minutes or for 60 minutes continuously.	 Sensor does not work (see section "Disturbances in comfort") Insufficient air circulation or blocked heat exchanger Defective control board in F2040 Too much refrigerant
262	Power transistor too hot	When IPM (Intelligent power module) displays FO-signal (Fault Output) five times during a 60-minute period.	Can occur when 15V power supply to the inverter PCB is unstable.
263	Inverter error	Voltage from the inverter outside the parameters four times within 30 minutes.	 Incoming power supply interference Service valve closed Insufficient amount of refrigerant Compressor fault Defective circuit board for inverter in F2040
264	Inverter error	Communication between circuit board for inverter and control board broken.	 Open circuit in connection between boards Defective circuit board for inverter in F2040 Defective control board in F2040
265	Inverter error	Continuous deviation on power transistor for 15 minutes.	 Defective fan motor Defective circuit board for inverter in F2040
266	Insufficient refrigerant	Insufficient refrigerant is detected upon start-up in cooling mode.	 Service valve closed Loose connection sensor (BT15, BT3) Defective sensor (BT15, BT3) Too little refrigerant
267	Inverter error	Failed start for compressor	 Defective circuit board for inverter in F2040 Defective control board in F2040 Compressor fault
268	Inverter error	Overcurrent, Inverter A/F module	Sudden power failure

NIBE F2040 Chapter 9 | Alarm list 55

Alarm	Alarm text on the display	Description	May be due to
271	Cold outdoor air	Temperature of BT28 below the value that	Cold weather conditions
		permits operation	Sensor fault
272	Hot outdoor air	Temperature of BT28 above the value that	Warm weather conditions
		permits operation	Sensor fault
277	Sensor fault Tho-R	Sensor fault, heat exchanger in F2040(Tho-R).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board in F2040
278	Sensor fault Tho-A	Sensor fault, outdoor temperature sensor in F2040 (Tho-A).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board in F2040
279	Sensor fault Tho-D	Sensor fault, hot gas in F2040 (Tho-D).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board in F2040
280	Sensor fault Tho-S	Sensor fault, suction gas in F2040 (Tho-S).	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board in F2040
281	Sensor fault LPT	Sensor fault, low pressure transmitter in F2040.	Open circuit or short circuit on sensor input
			Sensor does not work (see section "Disturbances in comfort")
			Defective control board in F2040
			Fault in the refrigerant circuit
294	Non-compatible air/water heat pump	Heat pump and indoor module do not work properly together due to technical parameters.	Outdoor module and indoor module are not compatible.
404	Sensor fault BP4	Sensor fault, Sensor high pressure heat-	Open circuit or short circuit on sensor input
		ing/low pressure cooling in F2040 (BP4).	Sensor does not work (see section "Disturbances in comfort")
			Defective control board AA23 in F2040

56 Chapter 9 | Alarm list NIBE F2040

10 Accessories

Not all accessories are available on all markets.

CONDENSATION WATER PIPE

Condensation water pipe, different lengths.

Earth circuit breaker 1-phase.

KVR 10-10 F2040 / HBS05

1 metres

Part no. 067 614

KVR 10-30 F2040 / HBS05

3 metres

Part no. 067 616

KVR 10-60 F2040 / HBS05

6 metres

Part no. 067 618

STAND AND BRACKETS

Ground stand

F2040-6, -8, -12, -16

Part no. 067 599

Wall bracket


F2040-6, -8, -12

Part no. 067 598

11 Technical data


Dimensions and setting-out coordinates

F2040-6




^{*} Accessory KVR 10 is required.

F2040-8




^{*} Accessory KVR 10 is required.

F2040-12




^{*} Accessory KVR 10 is required.

F2040-16



* Accessory KVR 10 is required.




Sound pressure levels

F2040 is usually placed next to a house wall, which gives a directed sound distribution that should be considered. Accordingly, you should always attempt when positioning to choose the side that faces the least sound sens-

itive neighbouring area.

The sound pressure levels are further affected by walls, bricks, differences in ground level, etc and should therefore only be seen as guide values.

F2040 adjusts the fan speed depending on the ambient temperature and evaporation temperature.



Air/water heat pump	F2040-6	F2040-8	F2040-12	F2040-16	
Sound power level* According to EN12102 at 7/45 (nominal)	L _W (A)	50	55	58	61
Sound pressure level at 2 m free standing.*	dB(A)	36	40	43	47
Sound pressure level at 6 m free standing.*	dB(A)	26.5	30.5	33.5	37.5
Sound pressure level at 10 m free standing.*	dB(A)	22	26	29	33

^{*} Free space.

Chapter 11 | Technical data

Technical specifications



Air/water heat pump		F2040-6	F2040-8	F2040-12	F2040-16
Output data according to EN 14511 ΔT5K	Outdoor temp./ Supply temp.				
Heating	7/35 °C (floor)	2.67/0.50/5.32	3.86/0.83/4.65	5.21/1.09/4.78	7.03/1.45/4.85
· ·	2/35 °C (floor)	2.32/0.55/4.20	5.11/1.36/3.76	6.91/1.79/3.86	9.33/2.38/3.92
Capacity / power input / COP (kW/kW/-) at nominal flow	-7/35 °C (floor)	4.60/1.79/2.57	6.60/2.46/2.68	9.00/3.27/2.75	12.1/4.32/2.80
at nominal now	7/45 °C	2.28/0.63/3.62	3.70/1.00/3.70	5.00/3.27/2.73	6.75/1.74/3.88
	2/45 °C	1.93/0.67/2.88	5.03/1.70/2.96	6.80/2.24/3.04	9.18/2.98/3.08
Cooling	27/7 °C	5.87/1.65/3.56	7.52/2.37/3.17	9.87/3.16/3.13	13.30/3.99/3.33
	27/18 °C	7.98/1.77/4.52	11.20/3.20/3.50	11.70/3.32/3.52	17.70/4.52/3.91
Capacity / Power input / EER (kW/kW/-)	35/7 °C	4.86/1.86/2.61	7.10/2.65/2.68	9.45/3.41/2.77	13.04/4.53/2.88
at maximum flow	35/18 °C	7.03/2.03/3.45	9.19/2.98/3.08	11.20/3.58/3.12	15.70/5.04/3.12
Electrical data	33/10 C	7.03/2.03/3.45	9.19/2.90/3.00	11.20/3.36/3.12	15.70/5.04/5.12
Rated voltage			230\/ -, 50Hz	230V 2 ~ 50Hz	
Max operating current, heat pump	Λ	15	16	23	25
Max operating current, near pump	A _{rms}	14	15	22	24
	A _{rms}	14	15	ļ	
Starting current	A _{rms}				0 - 00
Nominal output, fan	W	50	86	86	2 x 86
Fuse ¹⁾	A _{rms}	16	16	25	25
Enclosure class			IP.	24	
Refrigerant circuit		1			
Type of refrigerant				10A	
GWP refrigerant			2,0		
Type of compressor				Rotary	
Compressor oil				1A68	
Volume	kg	1.5	2.55	2.9	4.0
CO ₂ equivalent	t	3.13	5.32	6.06	8.35
Cut-out value pressostat HP	MPa	-		4.15 (41.5 bar)	
Cut-out value HP		4.15 (41.5 bar)		-	
Cut-out value pressostat LP	MPa	-		0.079 (0.79 bar)	
Brine					
Airflow	m³/h	2,530	3,000	4,380	6,000
Min. / Max. air temp.	°C		-20	/ 43	
Defrosting system			Revers	e cycle	
Heating medium circuit					
Min/Max system pressure heating medium	MPa		0.05/0.25 (0.5/4.5bar)	
Min volume, climate system, heating/cooling	I	20	50	80	150
Min volume, climate system, under floor cooling	I	50	80	100	150
Max flow, climate system	l/s	0.29	0.38	0.57	0.79
Min flow, climate system, at 100% circulation pump speed (defrosting flow)	l/s	0.19	0.19	0.29	0.39
Min flow, heating	l/s	0.09	0.12	0.15	0.25
Min flow, cooling	l/s	0.11	0.15	0.20	0.32
Min. / Max. HM temp continuous operation	°C		25,	/ 58	1
Connection heating medium ext thread	I.		G	1"	
Dimensions and weight		I.			
Width	mm	993	1035	1145	1145
Depth	mm	364	422	452	452
Height with stand	mm	791 (+50/-0)	895 (+50/-0)	995 (+50/-0)	1450 (+50/-0)
Weight (excl. packaging)	kg	66	90	105	135
Miscellaneous		1	<u>I</u>	1	l
IVIISCEIIAITEOUS					

¹⁾Specified output is limited with lower fusing.

SCOP & P_{DESIGNH}

SCOP & P _{designh} F2040 acc	cording to EN	14825							
F2040		6		8	1	2	1	16	
	P _{designh}	SCOP	P _{designh}	SCOP	P _{designh}	SCOP	P _{designh}	SCOP	
SCOP 35 Average climate	4.8	4.8	6.8	3.88	12	4.43	14,5	4.48	
SCOP 55 Average climate	5,3	3.46	7.0	3.22	10	3,37	14	3.43	
SCOP 35 Cold climate	4,0	3,65	9	3.55	11.5	3.63	15	3.68	
SCOP 55 Cold climate	5,6	2.97	10	2.78	13	2.85	16	2,9	
SCOP 35 Warm climate	4,2	6.45	8	5,7	12	5.8	15	5.95	
SCOP 55 Warm climate	4.76	4.58	8	4.58	12	4.7	15	4.8	

ENERGY RATING, AVERAGE CLIMATE

Model		F2040-6	F2040-8	F2040-12	F2040-16
Control module model		SMO	SMO	SMO	SMO
Temperature application	°C	35 / 55	35 / 55	35 / 55	35 / 55
The product's room heating efficiency class ¹⁾		A++/A++	A++ / A++	A++/A++	A++/A++
Space heating efficiency class of the system ²⁾		A+++ / A++	A+++ / A++	A+++ / A++	A+++ / A++


¹Scale for the product's room heating efficiency class A++ to G.

 $^{^2\}mbox{Scale}$ for the system's room heating efficiency class A+++ to G.

The reported efficiency of the package also takes the controller into account. If an external supplementary boiler or solar heating is added to the package, the overall efficiency of the package should be recalculated.


Working area

Compressor operation - heating



During shorter time it is allowed to have lower working temperatures on the water side, e.g. during start up.

Compressor operation – cooling




Capacity and COP

Capacity and COP at different supply temperatures. Maximum capacity including defrosting.


Max. capacity F2040-6

Heating output



COP F2040-6


66



Max specified output F2040-8


Heating output

(kW)



COP F2040-8

COP




Chapter 11 | Technical data NIBE F2040


Max specified output F2040-12

Heating output (kW) 16,00 14,00 12,00 10,00 8,00 6,00 4,00 2,00 0,00 -20 -15 -10 -5 5 10 35°C Outdoor temperature **■**45°C (°C) **-** 55°C


Max specified output F2040-16



COP F2040-12




COP F2040-16



Output with lower fuse rating than recommended


Supplied power F2040-12, fuse rating 16A





Supplied power F2040-12, fuse rating 20A


Heating output



Supplied power F2040-16, fuse rating 20A

Heating output





Energy labelling

INFORMATION SHEET

Supplier		NIBE					
Model		F2040-6	F2040-8	F2040-12	F2040-16		
Temperature application	°C	35 / 55	35 / 55	35 / 55	35 / 55		
Seasonal space heating energy efficiency class, average climate		A++ / A++	A++ / A++	A++ / A++	A++ / A++		
Rated heat output (P _{designh}), average climate	kW	5/5	7/7	12 / 10	15 / 14		
Annual energy consumption space heating, average climate	kWh	2,089 / 3,248	3,622 / 4,486	5,361 / 6,137	6,702 / 8,431		
Seasonal space heating energy efficiency, average climate	%	188 / 131	152 / 126	174 / 132	176 / 134		
Sound power level L _{WA} indoors	dB	35	35	35	35		
Rated heat output (P _{designh}), cold climate	kW	4/6	9/10	12 / 13	15 / 16		
Rated heat output (P _{designh}), warm climate	kW	4/5	8/8	12 / 12	15 / 15		
Annual energy consumption space heating, cold climate	kWh	2,694 / 4,610	6,292 / 9,016	7,920 / 11,461	10,040 / 13,629		
Annual energy consumption space heating, warm climate	kWh	872 / 1,398	1,879 / 2,371	2,765 / 3,445	3,370 / 4,183		
Seasonal space heating energy efficiency, cold climate	%	143 / 116	138 / 106	140 / 109	144 / 113		
Seasonal space heating energy efficiency, warm cli- mate	%	252 / 179	224 / 177	229 / 183	235 / 189		
Sound power level L _{WA} outdoors	dB	50	55	58	61		

DATA FOR ENERGY EFFICIENCY OF THE PACKAGE

Model		F2040-6	F2040-8	F2040-12	F2040-16
Control module model		SMO	SMO	SMO	SMO
Temperature application	°C	35 / 55	35 / 55	35 / 55	35 / 55
Controller, class			\	/	
Controller, contribution to efficiency	%		4	.0	
Seasonal space heating energy efficiency of the package, average climate	%	192 / 135	156 / 130	178 / 136	180 / 138
Seasonal space heating energy efficiency class of the package, average climate		A+++ / A++	A+++/A++	A++ / A++	A+++ / A++
Seasonal space heating energy efficiency of the package, cold climate	%	147 / 120	142 / 110	144 / 113	148 / 117
Seasonal space heating energy efficiency of the package, warm climate	%	256 / 183	228 / 181	233 / 187	239 / 193

The reported efficiency of the package also takes the controller into account. If an external supplementary boiler or solar heating is added to the package, the overall efficiency of the package should be recalculated.

TECHNICAL DOCUMENTATION

Model		F2040-6							
Type of heat pump		Air-w	vater						
			ust-water						
			-water						
		☐ Wate	er-water						
Low-temperature heat pump		Yes	X No						
Integrated immersion heater for additional h	eat	Yes	X No						
Heat pump combination heater		Yes	X No				-		
Climate		X Aver		Cold Warm					
Temperature application			age (55 °C)						
Applied standards				1 / EN12102					
Rated heat output	Prated	5.3	kW	Seasonal space heating energy efficiency	ης	131	%		
Declared capacity for space heating at part i				Declared coefficient of performance for space hea					
Declared capacity for space fleating at part i	oau anu at outu	ioor terripe	rature ij	temperature Tj	ung at part	. IOau ai iu c	n oataoo		
Tj = -7 °C	Pdh	4.7	kW	Tj = -7 °C	COPd	1.88	-		
Tj = +2 °C	Pdh	2.8	kW	Tj = +2 °C	COPd	3.26	-		
Tj = +7 °C	Pdh	1.8	kW	Tj = +7 °C	COPd	4.72	-		
Tj = +12 °C	Pdh	2.7	kW	Tj = +12 °C	COPd	6.47	-		
Tj = biv	Pdh	4.7	kW	Tj = biv	COPd	1.88	-		
Tj = TOL	Pdh	4.1	kW	Tj = TOL	COPd	1.77	-		
Tj = -15 °C (if TOL < -20 °C)	Pdh		kW	Tj = -15 °C (if TOL < -20 °C)	COPd		-		
Bivalent temperature	T _{biv}	-7	°C	Min. outdoor air temperature	TOL	-10	°C		
Cycling interval capacity	Pcych	-/	kW	Cycling interval efficiency	COPcyc	-10	-		
Degradation coefficient	Cdh	0.99	-	Max supply temperature	WTOL	58	°C		
2 09.4444.0 000	04.1	0.00		max cappy temperata.c	******				
Power consumption in modes other than ac	ctive mode			Additional heat					
Off mode	P _{OFF}	0.007	kW	Rated heat output	Psup	1.2	kW		
Thermostat-off mode	P _{TO}	0.012	kW		· ·				
Standby mode	P _{SB}	0.012	kW	Type of energy input		Electric			
Crankcase heater mode	P _{CK}	0	kW	77					
	1 311	-							
Other items									
Capacity control		Variable		Rated airflow (air-water)		2,526	m ³ /h		
Sound power level, indoors/outdoors	L _{WA}	35 / 50	dB	Nominal heating medium flow			m ³ /h		
Annual energy consumption	Q _{HF}	3,248	kWh	Brine flow brine-water or water-water heat pumps			m³/h		
Contact information				14 – Hannabadsvägen 5 – 285 21 Markaryd – Swed	,				

70 Chapter 11 | Technical data

Model			F2040-8							
Type of heat pump		Air-w	/ater							
		_	ust-water							
		I =	e-water							
			er-water							
Low-temperature heat pump			X No							
Integrated immersion heater for additional heat			X No							
Heat pump combination heater			X No							
Climate			☐ Yes ☑ No ☐ Average ☐ Cold ☐ Warm							
Temperature application										
Applied standards			Average (55 °C)							
Rated heat output	Prated	7	kW	Seasonal space heating energy efficiency	η_s	127	%			
Declared capacity for space heating at part load		1 '		Declared coefficient of performance for space hea						
beclared capacity for space fleating at part load	and at out	ioor terripe	arature ij	temperature Tj	tirig at part	i ioau ariu e	it outdoor			
Tj = -7 °C	Pdh	5.7	kW	Tj = -7 °C	COPd	2.01	-			
Tj = +2 °C	Pdh	3.9	kW	Tj = +2 °C	COPd	3.20	-			
Tj = +7 °C	Pdh	2.6	kW	Tj = +7 °C	COPd	4.21	-			
Tj = +12 °C	Pdh	2.0	kW	Tj = +12 °C	COPd	5.18	-			
Tj = biv	Pdh	5.7	kW	Tj = biv	COPd	2.01	-			
Tj = TOL	Pdh	5.7	kW	Tj = TOL	COPd	1.78	-			
Tj = -15 °C (if TOL < -20 °C)	Pdh		kW	Tj = -15 °C (if TOL < -20 °C)	COPd		-			
Bivalent temperature	T _{biv}	-7	°C	Min. outdoor air temperature	TOL	-10	°C			
Cycling interval capacity	Pcych	/	kW	Cycling interval efficiency	COPcvc	10	-			
Degradation coefficient	Cdh	0.97	-	Max supply temperature	WTOL	58	°C			
				a salah / as has salah						
Power consumption in modes other than active	mode			Additional heat						
Off mode	P _{OFF}	0.045	kW	Rated heat output	Psup	1.5	kW			
Thermostat-off mode	P _{TO}	0.048	kW							
Standby mode	P _{SB}	0.045	kW	Type of energy input		Electric				
Crankcase heater mode	P _{CK}	0.045	kW	71 37 1	ļ.					
				1						
Other items										
Capacity control		Variable		Rated airflow (air-water)		3,000	m³/h			
Sound power level, indoors/outdoors	L _{WA}	35 / 55	dB	Nominal heating medium flow		0.6	m³/h			
Annual energy consumption	Q _{HE}	4,486	kWh	Brine flow brine-water or water-water heat pumps			m³/h			
Contact information		erav Svste	ems – Box	14 – Hannabadsvägen 5 – 285 21 Markaryd – Swed	den					


Model			F2040-12							
Type of heat pump		Air-w	/ater							
			ust-water							
			e-water							
			er-water							
Low-temperature heat pump			X No							
Integrated immersion heater for additional heat			X No							
Heat pump combination heater			⋈ No							
Climate		X Avera	age	Cold Warm						
Temperature application			age (55 °C)	Low (35 °C)						
L Applied standards			EN14825 / EN14511 / EN12102							
Rated heat output	Prated	10	kW	Seasonal space heating energy efficiency	η_s	132	%			
Declared capacity for space heating at part load a	and at outo	loor tempe	erature Ti	Declared coefficient of performance for space hea		load and a	t outdoor			
and die odia			,	temperature Tj						
Tj = -7 °C	Pdh	8.9	kW	Tj = -7 °C	COPd	1.99	-			
Tj = +2 °C	Pdh	5.5	kW	Tj = +2 °C	COPd	3.22	-			
Tj = +7 °C	Pdh	3.5	kW	Tj = +7 °C	COPd	4.61	-			
Tj = +12 °C	Pdh	5.0	kW	Tj = +12 °C	COPd	6.91	-			
Tj = biv	Pdh	9.2	kW	Tj = biv	COPd	1.90	-			
Tj = TOL	Pdh	8.1	kW	Tj = TOL	COPd	1.92	-			
Tj = -15 °C (if TOL < -20 °C)	Pdh		kW	Tj = -15 °C (if TOL < -20 °C)	COPd		-			
Bivalent temperature	T _{biv}	-8	°C	Min. outdoor air temperature	TOL	-10	°C			
Cycling interval capacity	Pcych		kW	Cycling interval efficiency	COPcvc		-			
Degradation coefficient	Cdh	0.98	-	Max supply temperature	WTOL	58	°C			
Power consumption in modes other than active mode				Additional heat						
Off mode	P _{OFF}	0.002	kW	Rated heat output	Psup	1.9	kW			
Thermostat-off mode	P _{TO}	0.014	kW							
Standby mode	P _{SB}	0.015	kW	Type of energy input		Electric				
Crankcase heater mode	P _{CK}	0.035	kW							
Other items										
Capacity control	Variable			Rated airflow (air-water)		4.380	m³/h			
Sound power level, indoors/outdoors	L _{WA}	35 / 58	dB	Nominal heating medium flow		0.86	m ³ /h			
Annual energy consumption	Q _{HF}	6.137	kWh	Brine flow brine-water or water-water heat pumps		0.00	m ³ /h			
Contact information		- / -		14 – Hannabadsvägen 5 – 285 21 Markaryd – Swed	don.		111-/11			
CONTACT INTOTTIBLION	INIDE EII	ergy syste	1115 – DOX	14 – Hariilabausvayeri 5 – 205 2 Fiviaikaryu – Swed	ICII					


72 Chapter 11 | Technical data NIBE F2040

Model			F2040-16					
Type of heat pump		☑ Air-water						
		_	ust-water					
		I =	e-water					
		I ==						
		Wate	er-water					
Low-temperature heat pump			X No					
Integrated immersion heater for additional heat			X No					
Heat pump combination heater			Yes No					
Climate			■ Average □ Cold □ Warm					
Temperature application								
Applied standards								
Rated heat output	Prated	14	kW	Seasonal space heating energy efficiency	η_s	134	%	
Declared capacity for space heating at part load				Declared coefficient of performance for space hea		_		
beclared capacity for space fleating at part load	and at out	ioor terripe	arature ij	temperature Tj	ting at par	i ioau ariu e	at Outdoor	
Tj = -7 °C	Pdh	12.5	kW	Tj = -7 °C	COPd	2.01	-	
Tj = +2 °C	Pdh	7.6	kW	Tj = +2 °C	COPd	3.29	-	
Tj = +7 °C	Pdh	4.9	kW	Tj = +7 °C	COPd	4.68	-	
Tj = +12 °C	Pdh	6.8	kW	Tj = +12 °C	COPd	6.51	-	
Tj = biv	Pdh	12.7	kW	Tj = biv	COPd	1.95	-	
Tj = TOL	Pdh	11.0	kW	Tj = TOL	COPd	1.95	-	
Tj = -15 °C (if TOL < -20 °C)	Pdh		kW	$Tj = -15 ^{\circ}\text{C} \text{ (if TOL } < -20 ^{\circ}\text{C)}$			-	
Bivalent temperature	T _{biv}	-8	°C	Min. outdoor air temperature	TOL	-10	°C	
Cycling interval capacity	Pcych	-	kW	Cycling interval efficiency	COPcvc	10	-	
Degradation coefficient	Cdh	0.98	-	Max supply temperature	WTOL	58	°C	
				and the first of the second				
Power consumption in modes other than active mode				Additional heat				
Off mode	P _{OFF}	0.002	kW	Rated heat output	Psup	3.0	kW	
Thermostat-off mode	P _{TO}	0.016	kW	·	· ·			
Standby mode	P _{SB}	0.015	kW	Type of energy input		Electric		
Crankcase heater mode	P _{CK}	0.035	kW	77	l			
				1				
Other items								
Capacity control		Variable		Rated airflow (air-water)		6,000	m³/h	
Sound power level, indoors/outdoors	L _{WA}	35 / 61	dB	Nominal heating medium flow		1.21	m³/h	
Annual energy consumption	Q _{HE}	8,431	kWh	Brine flow brine-water or water-water heat pumps			m ³ /h	
Contact information	NIBE Energy Systems – Box 14 – Hannabadsvägen 5 – 285 21 Markaryd – Sweden							


Electrical circuit diagram


F2040-6







F2040-8

















Chapter 11 | Technical data



Item register

Electrical connection, 22

A	Electrical connections, 29
Accessories, 57	Addressing via cascade connection, 41
Addressing via cascade connection, 41	Ambient temperature sensor, 37
Adjustment, charge flow, 44	Communication, 38
Alarm list, 54	Connecting accessories, 28
Ambient temperature sensor, 37	Connection between F2040 and SMO, 39
Assembly, 8	Connections, 32
, .	External heating cable (KVR 10) (Accessory), 36
B	General, 29
Basic actions, 46	Power connection, 32
С	Energy labelling, 69
Charge pump, 27	Data for energy efficiency of the package, 69
Commissioning and adjusting, 42	Information sheet, 69
Adjustment, charge flow, 44	Technical documentation, 70
Compressor heater, 42	Environmental information, 5
Filling and venting the heating medium system, 42	External heating cable (KVR 10) (Accessory), 36
Preparations, 42	·
Readjusting, heating medium side, 44	F
Start-up and inspection, 43	F2040 does not communicate, 46
Communication, 38	F2040 is not operational, 46
Compressor heater, 42	Filling and venting the heating medium system, 42
Condensate drip tray, 9	G
Connecting accessories, 28	General, 26, 29
Connection between F2040 and SMO, 39	
Connections, 32	H
Connection to board (AA23, 50	High room temperature, 47
Connection to board (PWB1), 48	1
Control, 45	Important information, 4
Menu 5.11.1.1 – Heat pump EB101, 45	Environmental information, 5
D	Inspection of the installation, 6
D Delivery and handling, 8	Recovery, 5
Assembly, 8	Safety information, 4
Condensate drip tray, 9	Safety precautions, 4
Installation area, 9	Serial number, 4
Removing the covers, 11	Inspection of the installation, 6
Removing the covers, 11 Removing the front panel, 12	Installation area, 9
	L
Removing the side panel, 13	Large amount of water below F2040, 47
Supplied components, 10	List of components, 21
Transport and storage, 8	Low hot water temperature or no hot water, 47
Dimensions and setting-out coordinates, 58	Low room temperature, 47
Disturbances in comfort, 46	2011 Total Composition, 47
Troubleshooting, 46	M
Docking alternatives, 28	Marking, 4
E	Menu 5.11.1.1 – Heat pump EB101, 45
Flectrical circuit diagram, 74	

NIBE F2040 Item register 83

Ρ Pipe connections, 26 Charge pump, 27 Docking alternatives, 28 General, 26 Pipe connections flex hose, 27 Pipe coupling heating medium circuit, 26 Pressure drop diagram, 27 Water volumes, 26 Pipe connections flex hose, 27 Pipe coupling heating medium circuit, 26 Power connection, 32 Preparations, 42 Pressure drop diagram, 27 Readjusting, heating medium side, 44 Recovery, 5 Removing the covers, 11 Removing the front panel, 12 Removing the side panel, 13 Safety information, 4 Marking, 4 Symbols, 4 Symbols on F2040, 4 Sensor placement, 48 Connection to board (AA23, 50 Connection to board (PWB1), 48 Sensor placement in F2040, 51 Sensors etc., 48 Sensor placement in F2040, 51 Sensors etc., 48 Serial number, 4 Sound pressure levels, 62 Start-up and inspection, 43 Supplied components, 10 Symbols, 4 Symbols on F2040, 4 Т Technical data, 58 Dimensions and setting-out coordinates, 58 Electrical circuit diagram, 74 Sound pressure levels, 62 Technical Data, 63 Technical Data, 63 The heat pump design, 14 Component locations, 14 Electrical components, 25 Electrical connection, 22 List of components, 21 Transport and storage, 8 Troubleshooting, 46 Basic actions, 46 F2040 does not communicate, 46 F2040 is not operational, 46 High room temperature, 47 Large amount of water below F2040, 47 Low hot water temperature or no hot water, 47 Low room temperature, 47 Sensor placement, 48

84 Item register NIBE F2040

Contact information

AUSTRIA

KNV Energietechnik GmbH Gahberggasse 11, 4861 Schörfling

Tel: +43 (0)7662 8963-0

mail@knv.at knv.at

FINLAND

NIBE Energy Systems Oy Juurakkotie 3, 01510 Vantaa Tel: +358 (0)9 274 6970

info@nibe.fi nibe.fi

GREAT BRITAIN

NIBE Energy Systems Ltd 3C Broom Business Park, Bridge Way, S41 9QG Chesterfield Tel: +44 (0)845 095 1200

info@nibe.co.uk nibe.co.uk

POLAND

NIBE-BIAWAR Sp. z o.o. Al. Jana Pawla II 57, 15-703 Bialystok bld. 8, Yuliusa Fuchika str.

Tel: +48 (0)85 66 28 490

biawar.com.pl

SWITZERLAND

NIBE Wärmetechnik c/o ait Schweiz ΑG Industriepark, CH-6246 Altishofen Tel. +41 (0)58 252 21 00 info@nibe.ch nibe.ch

CZECH REPUBLIC

Družstevní závody Dražice - strojírna Vølund Varmeteknik A/S

Dražice 69, 29471 Benátky n. Jiz. Tel: +420 326 373 801 nibe@nibe.cz

nibe.cz

FRANCE

NIBE Energy Systems France SAS Zone industrielle RD 28

Rue du Pou du Ciel, 01600 Reyrieux Tel: +49 (0)5141 75 46 -0

Tél: 04 74 00 92 92 info@nibe.fr

nibe.fr

NETHERLANDS

NIBE Energietechniek B.V.

Tel: +31 (0)168 47 77 22

nibenl.nl

info@nibenl.nl

Tel: +7 831 419 57 06

kuzmin@evan.ru

nibe-evan.ru

RUSSIA

GERMANY

DENMARK

volundvt.dk

NIBE Systemtechnik GmbH Am Reiherpfahl 3, 29223 Celle

Industrivej Nord 7B, 7400 Herning

info@nibe.de

Tel: +45 97 17 20 33

info@volundvt.dk

NORWAY

ABK AS

nibe.de

Energieweg 31, 4906 CG Oosterhout Brobekkveien 80, 0582 Oslo Tel: (+47) 23 17 05 20

post@abkklima.no

nibe.no

SWEDEN

EVAN NIBE Energy Systems

Box 14

603024 Nizhny Novgorod Hannabadsvägen 5, 285 21 Markaryd

Tel: +46 (0)433-27 3000

info@nibe.se nibe.se

For countries not mentioned in this list, contact NIBE Sweden or check nibe.eu for more information.

NIBE Energy Systems Hannabadsvägen 5 Box 14 SE-285 21 Markaryd info@nibe.se nibe.eu

This manual is a publication from NIBE Energy Systems. All product illustrations, facts and data are based on the available information at the time of the publication's approval. NIBE Energy Systems makes reservations for any factual or printing errors in this manual.

