


Exhaust air heat pump

NIBE F372 3x400 V, 3x230 V



Quick guide


Navigation



A detailed explanation of the button functions can be found on page 39.

How to scroll through menus and make different settings is described on page 41.

Set the indoor climate



The mode for setting the indoor temperature is accessed by pressing the OK button twice, when in the start mode in the main menu.

Increase hot water volume



To temporarily increase the amount of hot water, first turn the control knob to mark menu 2 (water droplet) and then press the OK button twice.

Table of Contents

| | | | | | |
|-----------|---|-----------|--|--|--|
| 1 | Important information | 4 | | | |
| | Safety information | 4 | | | |
| | Symbols | 4 | | | |
| | Marking | 4 | | | |
| | Handling | 4 | | | |
| | Safety precautions | 5 | | | |
| | Serial number | 9 | | | |
| | Recovery | 9 | | | |
| | Inspection of the installation | 10 | | | |
| 2 | Delivery and handling | 11 | | | |
| | Transport | 11 | | | |
| | Assembly | 11 | | | |
| | Supplied components | 12 | | | |
| | Removing the covers | 12 | | | |
| | Removing parts of the insulation | 13 | | | |
| 3 | The heat pump design | 14 | | | |
| | General | 14 | | | |
| | Air treatment unit | 16 | | | |
| 4 | Pipe and ventilation connections | 17 | | | |
| | General pipe connections | 17 | | | |
| | Dimensions and pipe connections | 18 | | | |
| | Symbol key | 19 | | | |
| | Climate system | 19 | | | |
| | Cold and hot water | 19 | | | |
| | Installation alternative | 19 | | | |
| | General ventilation connection | 21 | | | |
| | Ventilation flow | 21 | | | |
| | Adjusting ventilation | 21 | | | |
| | Dimensions and ventilation connections | 21 | | | |
| 5 | Electrical connections | 22 | | | |
| | General | 22 | | | |
| | Connections | 24 | | | |
| | Settings | 26 | | | |
| | Optional connections | 26 | | | |
| | Connecting accessories | 29 | | | |
| 6 | Commissioning and adjusting | 30 | | | |
| | Preparations | 30 | | | |
| | Filling and venting | 30 | | | |
| | Start-up and inspection | 31 | | | |
| | Setting the heating curve | 36 | | | |
| 7 | myUplink | 38 | | | |
| | Specification | 38 | | | |
| | Connection | 38 | | | |
| | Range of services | 38 | | | |
| | myUplink PRO | 38 | | | |
| 8 | Control - Introduction | 39 | | | |
| | Display unit | 39 | | | |
| | Menu system | 39 | | | |
| 9 | Control - Menus | 43 | | | |
| | Menu 1 - INDOOR CLIMATE | 43 | | | |
| | Menu 2 - HOT WATER | 43 | | | |
| | Menu 3 - INFO | 44 | | | |
| | Menu 4 - HEAT PUMP | 44 | | | |
| | Menu 5 - SERVICE | 45 | | | |
| 10 | Service | 49 | | | |
| | Maintenance | 49 | | | |
| | Service actions | 49 | | | |
| 11 | Disturbances in comfort | 53 | | | |
| | Info menu | 53 | | | |
| | Manage alarm | 53 | | | |
| | Troubleshooting | 53 | | | |
| 12 | Accessories | 55 | | | |
| 13 | Technical data | 56 | | | |
| | Dimensions | 56 | | | |
| | Technical specifications | 57 | | | |
| | Energy labelling | 61 | | | |
| | Electrical circuit diagram | 63 | | | |
| | Item register | 75 | | | |
| | Contact information | 79 | | | |

Important information

Safety information

This manual describes installation and service procedures for implementation by specialists.

The manual must be left with the customer.

For the latest version of the product's documentation, see nibe.eu.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This is an original manual. It may not be translated without the approval of NIBE.

Rights to make any design or technical modifications are reserved.

©NIBE 2024.

Water may drip from the safety valve. A factory-fitted overflow pipe runs from the safety valve to an overflow cup. An overflow pipe has to be routed from the overflow cup to a suitable drain. The overflow pipe must be inclined along its entire length to prevent pockets where water can accumulate, and must be frost-proof.

F372 must be installed via an isolator switch. The cable area has to be dimensioned based on the fuse rating used.

If the supply cable is damaged, only NIBE, its service representative or similar authorised person may replace it to prevent any danger and damage.

Symbols

Explanation of symbols that may be present in this manual.



WARNING!

This symbol indicates serious danger to person or machine.



CAUTION!

This symbol indicates danger to person or machine.



NOTE!

This symbol indicates important information about what you should consider when installing or servicing the installation.



TIP!

This symbol indicates tips on how to facilitate using the product.

Marking

Explanation of symbols that may be present on the product's label(s).



Fire hazard!



Read the User Manual.



Read the Installer Manual.

Handling

The heat pump contains a highly flammable refrigerant. For this reason, take special care during handling, installation, service, cleaning and scrapping to prevent damage to the refrigerant system and thus reduce the risk of leakage.



CAUTION!

Work on refrigerant systems must be carried out by personnel who have knowledge and experience of working with flammable refrigerants.

Safety precautions



WARNING!

Do not use agents to speed up the defrosting process or for cleaning, other than those recommended by the manufacturer.

The apparatus must be stored in a room with no continuous ignition sources (e.g. naked flame, an active gas installation or an active electric heater).

Must not be punctured or burned.

Be aware that the refrigerant may be odourless

GENERAL

Pipe installation should be kept to a minimum.

AREA CHECKS

Before work is started on systems that contains combustible refrigerants, safety checks must be performed to ensure that the ignition risk is kept to a minimum.

WORKING METHOD

The work must be carried out in a controlled way to minimise the risk of contact with combustible gas or liquid during the work.

GENERAL FOR THE WORKING RANGE

All maintenance staff and those who work in close proximity to the product must be instructed which type of work is to be carried out. Avoid carrying out work in enclosed spaces. The area surrounding the worksite must be cordoned off. Ensure that the area is made safe by removing combustible material.

CHECK FOR THE PRESENCE OF REFRIGERANT

Check whether there is refrigerant in the area using a suitable refrigerant detector prior to and during work, to notify the service technician whether there is a possible flammable atmosphere or not. Ensure that the refrigerant detector is suitable for

combustible refrigerant, i.e. does not generate sparks or cause ignition in any other way.

PRESENCE OF FIRE EXTINGUISHERS

If hot work is carried out on the heat pump, a powder or carbon dioxide fire extinguisher must be to hand.

ABSENCE OF IGNITION SOURCES

Pipes connected to the unit must not contain potential sources of ignition.

Those who carry out work with refrigerant system connections, including exposing pipes that contain or have contained combustible refrigerant, may not use potential ignition sources in such a way that that can lead to risks of fire or explosions.

All potential ignition sources, including cigarette smoking, should be kept at a safe distance from the service work area where combustible refrigerant can leak out. Before carrying out work, the area surrounding the equipment must be checked to ensure that there are no ignition risks. "No smoking" signs must be displayed.

VENTILATED AREA

Ensure that the work is carried out outdoors or that the work area is ventilated before the system is opened and before any hot work is carried out. The area must be ventilated whilst the work is being carried out. There must be ventilation around any refrigerant that comes out, which should be routed outdoors.

CHECKING COOLING EQUIPMENT

If electrical components are replaced, the replacement parts must be fit for purpose and have the correct technical specifications. Always follow the manufacturer's guidelines regarding maintenance and servicing. Contact the manufacturer's technical department in the event of any doubts. The following checks must be carried out for installations that use combustible refrigerants.

- The actual filling quantity is appropriate for the magnitude of the space where the parts containing refrigerant are installed.
- Ventilation equipment and outlet work correctly and without obstructions.
- If an indirect refrigerant circuit is used, check whether the secondary circuit contains refrigerant.
- All markings of equipment are visible and clear. Markings, signs and similar that are not clear must be replaced.
- Refrigerant pipes and components are positioned in such a way that it is not likely that they be subjected to substances that can corrode components containing refrigerant, if these components are not made of material that is resistant against corrosion, or not appropriately protected against such corrosion.

CHECKING ELECTRICAL EQUIPMENT

Repair and maintenance of electrical components must include initial safety checks and procedures for component inspection. In the event of a fault, which can cause a safety risk, do not supply any power to the circuit until the fault has been rectified. If the fault cannot be rectified immediately, and operation must continue, an adequate temporary solution must be implemented. This must be reported to the equipment owner, so that all parties have been informed.

The following checks must be carried out at the initial safety checks.

- That the capacitors are discharged. Discharging must be done safely, to prevent the risk of sparking.
- That no powered electrical components or live cables are exposed when filling or collecting refrigerant or when the system is flushed.
- That the system is continually earthed.

REPAIRING SEALED COMPONENTS

When repairing sealed components, all electrical supply must be disconnected from the equipment that is being repaired

before any sealed covers or similar are removed. If it is absolutely necessary to have an electricity supply to the equipment during the service, continuously activated leak tracing must be performed at the most critical points in order to warn of any dangerous situations.

Pay particular attention to the following so that the sheath is not changed in a way that affects the protection level when working with electrical components. This means damage to cables, unnecessary amounts of connections, terminals that do not follow the original specifications, damaged gas-kets, incorrect grommets etc.

Ensure that the apparatus is secured properly.

Check that seals or sealing materials have not deteriorated to a degree that they can no longer prevent combustible gases from entering. Replacement parts must meet the manufacturer's specifications.



CAUTION!

Use of silicone seals can hamper the efficiency of certain types of leak-tracing equipment. Components with built in safety do not need to be isolated before starting work.

WIRING

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

LEAK TESTING

The following leak detection methods are deemed acceptable for systems containing flammable refrigerants.

Electronic leak tracers must be used to detect combustible refrigerant; but the leak tracer may not be sufficiently sensitive or may need to be recalibrated (the leak tracing equipment must be calibrated in an area completely free from refrigerant). The

leak tracer must not be a potential source of ignition and must be suitable for the relevant refrigerant. The leak tracing equipment must be set and calibrated for the relevant refrigerant, to ensure that the gas concentration is a maximum of 25% of the lowest combustible concentration (Lower Flammability Limit, LFL) of the relevant refrigerant.

Leak detection fluids are suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leak that requires brazing is detected, all refrigerant must be removed from the system and stored in a separate container. Alternatively, the refrigerant can be stored separated from the brazing area in a part of the system at a safe distance from the leak, if this part of the system can be disconnected safely with shut-off valves. The system must be emptied in accordance with the section "Removal and draining".

REMOVAL AND DRAINING

When a cooling circuit is opened for repairs – or for another reason – work must be carried out in a conventional manner. Due to the risk of fire it is important that best practice is applied. Follow the procedure below.

1. Safely remove the refrigerant in accordance with applicable local and national regulations.
2. Drain the circuit.
3. Flush the circuit with inert gas.
4. Drain the circuit.
5. Flush the circuit continuously with inert gas when using a cutting or brazing method to open the circuit.
6. Open the circuit.

Collect the refrigerant in the intended cylinders. Clean the system with oxygen-free nitrogen to make the unit safe. This process

may need to be repeated several times. Compressed air and oxygen must not be used.

Clean the system by breaking the vacuum with oxygen-free nitrogen, and filling the system to working pressure, relieving the pressure to atmospheric pressure and finally pumping to vacuum. Repeat the process until no refrigerant remains in the system. After the final filling with oxygen-free nitrogen, relieve the pressure in the system to atmospheric pressure, so that work can be carried out. This type of flushing must always be carried out if hot work is to be performed on the pipe system.

Ensure that the vacuum pump's outlet is not near to any potential ignition sources and that there is satisfactory ventilation by the outlet.

FILLING

In addition to the conventional filling procedures, the following actions must be taken.

- Ensure that different refrigerants are not mixed when filling equipment is used. Hoses and lines must be as short as possible to minimise the enclosed refrigerant volume.
- Containers must be stored in a suitable position in accordance with the instructions.
- Ensure that the cooling system is grounded before the system is filled with refrigerant.
- Mark the system once filling is complete (if not already marked). If the amount differs from the pre-installed amount, the marking must include the pre-installed amount, the added extra amount and the total amount.
- Take extra care not to overfill the cooling system.

Before refilling the system, pressure test it with oxygen-free nitrogen. Leak test the system after filling but before using the system. Perform an additional leak test before leaving the installation.

DECOMMISSIONING

Before the device is taken out of operation, the technician must without exception be very familiar with the equipment and all its component parts. Good practice prescribes that all refrigerant is collected safely. Before the collected refrigerant can be reused, oil and refrigerant samples must be taken, if analysis is required. There must be a power supply when this task is started.

1. Familiarise yourself with the equipment and its use.
2. Isolate the system electrically.
3. Before starting the procedure, ensure that:
 - necessary equipment for mechanical handling of the refrigerant container is available
 - all necessary personal safety equipment is available and used correctly
 - the collection process is continuously supervised by an authorised person
 - the collection equipment and containers meet appropriate standards.
4. Pump the refrigerant system to vacuum, if possible.
5. If it is not possible to pump to vacuum, manufacture a branch, so that the refrigerant can be retrieved from different parts of the system.
6. Check that the refrigerant container is on the scales before starting to collect.
7. Start the collection device and collect according to the manufacturer's instructions.
8. Do not overfill the containers (max. 80 % (volume) liquid content).
9. Do not exceed the containers' maximum permitted working pressure – not even temporarily.

10. When the containers have been filled correctly and the process is complete, close all shut-off valves in the equipment and remove and containers and equipment from the installation immediately.
11. The collected refrigerant must not be filled in any other system before being cleaned and checked.

Marking

The equipment must be marked stating that it has been taken out of operation and drained of refrigerant. The marking must be dated and signed. Check that the equipment is marked indicating that it contains combustible refrigerant.

Collection

Best practice prescribes that all refrigerant is collected safely when the refrigerant is drained from a system, either for servicing or for decommissioning.

The refrigerant must only be collected in suitable refrigerant containers. Ensure that the required number of containers, which can hold the entire volume of the system, are available. All containers that are to be used must be intended for the collection of the refrigerant and marked for this refrigerant (specifically designed for the collection of refrigerant). The containers have to be equipped with correctly functioning pressure relief valves and shut-off valves. Empty collection containers must be drained and, if possible, chilled before collection.

The collection equipment must function correctly and instructions for the equipment must be to hand. The equipment must be suitable for the collection of combustible refrigerant.

Fully functioning and calibrated scales must also be to hand.

Hoses must be in good condition and be equipped with leak-proof quick couplings. Before using the collecting machine, check that it is working correctly and has been properly maintained. Associated electrical

components must be sealed, to prevent ignition if any refrigerant should leak out. Contact the manufacturer if you are in any doubt.

Return the collected refrigerant to the refrigerant supplier in the correct collection container and with the relevant Waste Transfer Note. Do not mix refrigerants in collection devices or containers.

If compressors or compressor oil are to be removed, ensure that the affected device is drained to an acceptable level to ensure that no combustible refrigerant remains in the lubricant. Compressors must be drained before being returned to the supplier. The compressor housing must not be heated using a naked flame or any other type of ignition source to speed up drainage. Drain oil from the system in a safe manner.

MISCELLANEOUS

Maximum amount of refrigerant: See Technical Specifications in the Installer Manual.


- Everyone who works with or opens a refrigerant circuit must have a current, valid certificate from an accredited industry issuing body, which states that, according to the industry's recognised assessment standard, they have the authority to safely handle refrigerants.
- Servicing must only be performed according to the equipment manufacturer's recommendations.

Maintenance and repairs that require the assistance of another trained person must be carried out under the supervision of person with the authority to handle combustible refrigerants.

Maintenance and repair that requires the skill of another person must be carried out under the supervision of someone with the above expertise.

Serial number

The serial number can be found at the bottom right of the front cover, in the info menu (menu 3.1) and on the type plate (PZ1).



NOTE!

You need the product's (14 digit) serial number for servicing and support.

Recovery



Leave the disposal of the packaging to the installer who installed the product or to special waste stations.

Do not dispose of used products with normal household waste. It must be disposed of at a special waste station or dealer who provides this type of service.

Improper disposal of the product by the user results in administrative penalties in accordance with current legislation.

Inspection of the installation

Current regulations require the heating installation to undergo an installation inspection before it is commissioned. The inspection must be carried out by a suitably qualified person. In addition, fill in the page for information regarding the installation data in the User Manual.

| ✓ | Description | Notes | Signature | Date |
|---|--------------------------------------|-------|-----------|------|
| | Ventilation (page 21) | | | |
| | Setting ventilation flow exhaust air | | | |
| | Connecting ground cables | | | |
| | Heating medium (page 19) | | | |
| | System flushed | | | |
| | System vented | | | |
| | Circulation pump setting | | | |
| | Pressure in the climate system | | | |
| | Electricity (page 22) | | | |
| | Connections | | | |
| | Main voltage | | | |
| | Phase voltage | | | |
| | Fuses heat pump | | | |
| | Fuses property | | | |
| | Outside sensor | | | |
| | Room sensor | | | |
| | Current sensor | | | |
| | Safety breaker | | | |
| | Earth circuit-breaker | | | |

Delivery and handling


Transport

F372 should be transported and stored vertically in a dry place.

Ensure that the heat pump cannot fall over during transport.


Check that F372 has not been damaged during transport.

However, the F372 can be carefully laid on its back when being moved into the building. The centre of gravity is in the top section.



Assembly


- Position F372 on a solid foundation indoors that withstands water and the weight of the product.
- Use the product's adjustable feet to attain a horizontal and stable set-up.



- Since water comes from F372, the area where F372 is located must be equipped with floor drainage.
- Because water comes from F372, the floor coating is important. A waterproof floor or floor membrane is recommended.
- Install with its back to an outside wall, ideally in a room where noise does not matter, in order to eliminate noise problems. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem.
- Wherever the unit is located, walls to sound sensitive rooms should be fitted with sound insulation.
- Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.
- The installation area always has to have a temperature of at least 10 °C and max. 30 °C.

INSTALLATION AREA

Leave a free space of 800 mm in front of the product. Leave free space between F372 and wall/other machinery/fittings/cables/pipes etc. It is recommended that a space of at least 10 mm is left to reduce the risk of noise and of any vibrations being propagated.



CAUTION!

Ensure that there is sufficient space (300 mm) above F372 for connecting ventilation ducts.

Supplied components



Outdoor temperature sensor
(BT1)



Room sensor(BT50)



Earth cabling (2 pcs)



Current sensor


LOCATION

The kit of supplied items is placed on top of the product.

Removing the covers


FRONT COVER

1. Remove the upper panel by pulling it straight out.
2. Remove the screws from the lower edge of the front panel.




3. Lift the panel out at the bottom edge and up.

4. Pull the panel towards yourself.




SIDE PANELS

1. Remove the screws from the upper and lower edges.




2. Twist the panel slightly outwards.




INSULATION, TOP

Grip the handle and pull straight out as illustrated.



3. Move the panel backwards and slightly to the side.




4. Assembly takes place in the reverse order.

Removing parts of the insulation

Parts of the insulation can be removed to facilitate the installation.

The heat pump design

General



PIPE CONNECTIONS

| | |
|-----|--|
| XL1 | Connection, heating medium flow line |
| XL2 | Connection, heating medium return line |
| XL3 | Connection, cold water |
| XL4 | Connection, hot water |
| XL8 | Connection, docking in |

HVAC COMPONENTS

| | |
|------|--|
| CM1 | Expansion vessel |
| FL1 | Safety valve, water heater |
| FL2 | Safety valve, climate system |
| FQ1 | Mixing valve, hot water |
| GP1 | Circulation pump |
| QM10 | Filler valve, hot water heater |
| QM11 | Filler valve, climate system |
| QM13 | Filling valve 2, climate system |
| QM20 | Vent valve, heating medium |
| QM31 | Shut-off valve, heating medium flow |
| QM32 | Shut off valve, heating medium return |
| QN11 | Shunt valve |
| WM1 | Overflow cup |
| WM2 | Overflow water discharge |
| WP1 | Overflow pipe, safety valve hot water heater |
| WP2 | Overflow pipe, safety valve climate system |
| WP3 | Overflow pipe, condensation |

SENSORS ETC.

| | |
|------|--|
| BP5 | Pressure gauge, heating system |
| BT2 | Temperature sensors, heating medium flow |
| BT3 | Temperature sensors, heating medium return |
| BT6 | Controlling hot water sensor |
| BT7 | Display hot water sensor |
| BT18 | Temperature sensor, compressor operation |
| BT19 | Temperature sensor, immersion heater operation |
| BT30 | Thermostat, backup heating |

ELECTRICAL COMPONENTS



| | |
|------|-----------------------------|
| AA1 | Immersion heater card |
| AA2 | Base card |
| AA3 | Input circuit board |
| AA4 | Display unit |
| | AA4-XF3 USB port |
| | AA4-XF4 Service socket |
| EB1 | Immersion heater |
| FC1 | Miniature circuit-breaker |
| FQ10 | Temperature limiter |
| MA1 | Shunt motor with hand wheel |
| RF3 | EMC card |
| SF1 | Switch |
| W130 | Network cable for myUplink |

MISCELLANEOUS

| | |
|-------|---------------------|
| PZ1 | Rating plate |
| PZ3 | Serial number plate |
| UB1-2 | Cable gland |

Designations according to standard EN 81346-2.

Air treatment unit



VENTILATION CONNECTIONS

- XL31 Ventilation connection, exhaust air
- XL32 Ventilation connection, extract air

SENSORS ETC.

- BP1 High pressure pressostat
- BP2 Low pressure pressostat
- BT16 Temperature sensor, evaporator
- BT20 Temperature sensor, exhaust air
- BT21 Temperature sensor, extract air

ELECTRICAL COMPONENTS

- AA100 Connection card air treatment section, exhaust air
- CA1 Capacitor
- EB10 Compressor heater
- FQ14 Temperature limiter, compressor

COOLING COMPONENTS

- EP1 Evaporator
- GQ10 Compressor
- HZ2 Drying filter
- QN1 Expansion valve

VENTILATION

- GQ2 Exhaust air fan
- HQ10 Exhaust air filter¹
- QQ1 Filter cover, exhaust air

¹ Not visible in the image

Pipe and ventilation connections

General pipe connections

Pipe installation must be carried out in accordance with current norms and directives.

The system requires the radiator circuit to be designed for a low temperature heating medium. At the lowest dimensioned outdoor temperature (DOT) the highest recommended temperatures are 55 °C on the supply line and 45 °C on the return line.



NOTE!

Ensure that incoming water is clean. When using a private well, it may be necessary to supplement with an extra water filter.



CAUTION!

The pipe systems have to be flushed clean before the product is connected, to prevent any contaminants from damaging the components.




CAUTION!

Water may drip from the safety valve. A factory-fitted overflow pipe runs from the safety valve to an overflow cup. An overflow pipe has to be routed from the overflow cup to a suitable drain. The overflow pipe must be inclined along its entire length to prevent pockets where water can accumulate, and must be frost-proof.

SYSTEM VOLUME

F372 is equipped with an expansion vessel (CM1).

The volume of the expansion vessel is 10 litres and it is pre-pressurised as standard to 0.5 bar. As a result, the maximum permitted height "H" between the expansion vessel and the highest installed radiator is 5 m, see figure.



If the pre-pressure is not high enough, it can be increased by filling with air via the valve in the expansion vessel. Any change in the pre-pressure affects the ability of the expansion vessel to handle the expansion of the water.

The maximum system volume, excluding F372, is 219 litres at the above-mentioned pre-pressure.

SYSTEM DIAGRAM

F372 consists of a heat pump, water heater, immersion heater, fan, circulation pump and control system. F372 is connected to the ventilation system and the climate system.


When the exhaust air at room temperature passes through the evaporator, the refrigerant evaporates because of its low boiling point. As a result, the air releases energy to the refrigerant.

The refrigerant is then compressed in the compressor, causing the temperature to rise considerably.

The warm refrigerant is led to the condenser. Here, the refrigerant gives off its energy to the climate system's water, whereupon the refrigerant changes state from gas to liquid.

The refrigerant then goes via filters to the expansion valve, where the pressure and temperature are reduced.

The refrigerant has now completed its circulation and returns to the evaporator.



Pipe connections


- XL1 Connection, heating medium flow line
- XL2 Connection, heating medium return line
- XL3 Connection, cold water
- XL4 Connection, hot water
- XL8 Connection, docking in



NOTE!


This is a principle of operation. For more detailed information about F372, see section "The heat pump design".

Dimensions and pipe connections



The overflow cup (WM1) can be turned, allowing the pipe to be pointed forwards or backwards to simplify connection to the drain.

SETTING OUT DIMENSIONS



| Connection | | A | B | C |
|---------------------------|------|-----|-----|-----|
| XL1 Heating medium supply | (mm) | 135 | 360 | 65 |
| XL2 Heating medium return | (mm) | 215 | 425 | 385 |
| XL3 Cold water | (mm) | 200 | 455 | 215 |
| XL4 Hot water | (mm) | 180 | 405 | 265 |
| XL8 Docking | (mm) | 220 | 290 | 300 |
| WM1 Overflow cup | (mm) | 95 | 205 | 430 |

PIPE DIMENSIONS

| Connection | | |
|-------------------------------------|------|----|
| XL1-XL2 Heating medium ext θ | (mm) | 22 |
| XL3 Cold water ext θ | (mm) | 22 |
| XL4 Hot water ext θ | (mm) | 22 |
| XL8 Docking ext. θ | (mm) | 22 |
| WM2 Overflow water discharge | (mm) | 32 |

Symbol key

| Symbol | Meaning |
|---|---------------------------------------|
|  | Unit box |
|  | Non-return valve |
|  | Mixing valve |
|  | Circulation pump |
|  | Immersion heater |
|  | Expansion valve |
|  | Fan |
|  | Compressor |
|  | Temperature sensor |
|  | Trim valve |
|  | Reversing valve/shunt |
|  | Overflow valve |
|  | Domestic hot water |
|  | Hot water circulation |
|  | Heat pump |
|  | Heating system |
|  | Heating system with lower temperature |


Climate system

A climate system is a system that regulates the indoor temperature with the help of the control system in F372 and, for example, radiators, underfloor heating, fan coils, etc.

CONNECTING THE CLIMATE SYSTEM


Install as follows:

- When connecting to a system with thermostats, either a bypass valve must be fitted or, alternatively, some of the thermostats must be removed to ensure there is sufficient flow and heat emission.



Cold and hot water

The settings for hot water are made in menu 5.1.1.



Installation alternative

F372 can be installed in several different ways, some of which are shown here.

Further option information is available at nibe.eu and in the respective assembly instructions for the accessories used. See page 55 for a list of the accessories that can be used with F372.

EXTRA HOT WATER HEATERS

The system should be supplemented with an extra water heater, if a large bath tub or other significant consumer of hot water is installed.


Water heater with immersion heater

If there is the option to use a water heater with an immersion heater, NIBE COMPACT or NIBE EMINENT type water heaters can be used.

In a water heater with an immersion heater, the water is initially heated by the heat pump. The immersion heater in the water heater is used for keeping warm and when the heat pump does not have sufficient power.

The water heater's flow is connected after F372.

If the valve connector is to be installed externally, moved out or separated, it must be replaced with a separable connector \varnothing 22 mm.




HOT WATER CIRCULATION

A circulation pump can be controlled by F372 to circulate the hot water. The circulating water must have a temperature that prevents bacterial growth and scalding, and national standards must be satisfied.

The HWC return is connected to a freestanding water heater.


The circulation pump is activated via the AUX output in menu 5.4 - "soft in/outputs".



EXTRA CLIMATE SYSTEM

In buildings with several climate systems that require different supply temperatures, the accessory ECS 40/ECS 41 can be connected.

ECS 40/ECS 41 is connected to connection, docking in (XL8).



General ventilation connection

- Ventilation installation must be carried out in accordance with current norms and directives.
- Connections must be made via flexible hoses, which should be installed so that they are easy to replace.
- Provision must be made for inspection and cleaning of the duct.
- Make sure that there are no reductions of cross-sectional area in the form of creases, tight bends, etc., since this will reduce the ventilation capacity.
- The air duct system must be a minimum of air tightness class B.
- To prevent fan noise being transferred to the ventilation devices, install silencers in suitable locations in the duct system.
- The extract air duct has to be insulated with diffusion-proof material along its entire length.
- Ensure that the condensation insulation is fully sealed at any joints and/or at lead-in nipples, silencers, roof cowls or similar.
- The extract air duct must be a maximum of 20 m long with a maximum of six bends.
- Because the heat pump contains a flammable refrigerant, the air ducting system must be earthed. This is done by making a good electrical connection to the air ducts using the enclosed earth cables (2). The cables must then be connected to the earth pins on top of the top cover.
- A duct in a masonry chimney stack must not be used for extract air.

EXHAUST AIR DUCT /KITCHEN FAN

Exhaust air duct (kitchen fan) must not be connected to F372.

To prevent cooking odours from being led to the F372, the distance between the kitchen fan and the exhaust air valve must be taken into consideration. The distance must not be less than 1.5 m, but may vary between different installations.

Always use a kitchen fan when cooking.

Ventilation flow

Connect F372 so that all the exhaust air, except kitchen duct air (kitchen fan), passes through the evaporator (EP1) in the heat pump.

The ventilation flow must comply with the applicable national standards.

For optimum heat pump performance, the ventilation flow must not be less than 28 l/s (100 m³/h) at an exhaust air temperature of at least 20 °C. When the exhaust air temperature is lower than 20 °C (for example at start-up and when there is nobody at home), the minimum value is 31 l/s (110 m³/h).

The heat pump's installation area must be ventilated to at least 5 l/s (18 m³/h)

Set the ventilation capacity in the heat pump's menu system (menu 5.1.5 - "fan sp. exhaust air").

If the exhaust air temperature falls below 16 °C, the compressor is blocked and electric additional heat is permitted. No energy is recovered from the exhaust air when the compressor is blocked.



Adjusting ventilation

To obtain the necessary air exchange in every room of the house, the exhaust air devices must be correctly positioned and adjusted and the fan in the heat pump adjusted.

Immediately after installation adjust the ventilation so that it is set according to the projected value of the house.

Incorrect adjustment of the ventilation may lead to reduced installation efficiency and thus poorer operating economy, a poorer indoor climate and moisture damage in the building.

Dimensions and ventilation connections




Electrical connections

General

All electrical equipment, except the outdoor sensors, room sensors and the current sensors are ready connected at the factory.

- Electrical installation and wiring must be carried out in accordance with national provisions.
- Disconnect F372 before insulation testing the house wiring.
- F372 must be fitted with a residual current device. If the property is equipped with a residual current device, F372 must be equipped with a separate one.
- F372 must be installed via an isolator switch. The cable area has to be dimensioned based on the fuse rating used.
- If a miniature circuit breaker is used, this must have at least triggering characteristic "C". See section "Technical specifications" for fuse size.
- To prevent interference, communication cables to external connections must not be laid in the vicinity of high voltage cables.
- The minimum area of communication and sensor cables to external connections must be 0.5 mm² up to 50 m, for example EKKX, LiYY or equivalent.
- For an electrical wiring diagram for F372, see the "Technical specifications" section.
- When routing a cable into F372, the cable grommets (UB1) and (UB2) must be used.



CAUTION!

Electrical installation and any servicing must be carried out under the supervision of a qualified electrician. Turn off the power with the circuit breaker before servicing.



CAUTION!

If the supply cable is damaged, only NIBE, its service representative or similar authorised person may replace it to prevent any danger and damage.




CAUTION!

Check the connections, main voltage and phase voltage before the product is started, to prevent damage to the heat pump electronics.



CAUTION!

Do not start the system before filling up with water. Components in the system could be damaged.



MINIATURE CIRCUIT-BREAKER (FC1)

Operation (230 V), fan, compressor, circulation pump, etc., are internally fused by a miniature circuit breaker (FC1).



NOTE!

Check the miniature circuit-breaker (FC1). It may have tripped during transport.

TEMPERATURE LIMITER (FQ10)

The temperature limiter (FQ10) cuts the current supply to the electric additional heat if the temperature rises between 90 and 100°C and can be manually reset.

Resetting

The temperature limiter (FQ10) is accessible behind the front cover. Reset the temperature limiter by carefully pressing the button (FQ10-SF2) using a small screwdriver.

ACCESSIBILITY, ELECTRICAL CONNECTION


The plastic cap of the electrical boxes is opened using a screwdriver.



CAUTION!


The cover for the input card is opened without a tool.

Removing the cover, input board



1. Push the catch down.
2. Angle out the cover and remove it.

Removing the cover, immersion heater board




1. Insert the screwdriver (A) and pry the catch carefully downwards (B).
2. Angle out the cover and remove it.

Removing the cover, base circuit board



NOTE!


To remove the cover for the base board, the cover for the input circuit board must first be removed.



1. Insert the screwdriver (A) and pry the catch carefully downwards (B).
2. Angle out the cover and remove it.

CABLE LOCK

Use a suitable tool to release/lock cables in the heat pump terminal blocks.




Connections

POWER CONNECTION

F372 must be installed via an isolator switch. The cable area has to be dimensioned based on the fuse rating used.


The enclosed cable (length approx. 2 m) for the incoming supply electricity is connected to terminal block X1 on the electric addition PCB (AA1).

The connection cable can be found on the reverse of F372 (see dimensions diagram below).




CAUTION!
F372 cannot be switched between 3x230 V and 3x400 V.

Connection 3x400V



Connection 3x230V



If a separate supply to the compressor and immersion heater is required, see section "Possible selection for AUX inputs" on page 28.

TARIFF CONTROL

If the voltage to the immersion heater and/or the compressor disappears for a certain period, there must also be blocking via the AUX-input at the same time, see "Possible selection for AUX inputs".

CONNECTING EXTERNAL OPERATING VOLTAGE FOR THE CONTROL SYSTEM


CAUTION!
Only applies to power connection 3x400 V.

CAUTION!
Mark the relevant electrical cabinet with a warning about external voltage, in those cases where a component in the cabinet has a separate supply.

If you wish to connect external operating voltage for the control system to F372 on the immersion heater circuit board (AA1) the edge connector at AA1:X2 must be moved to AA1:X9 (as illustrated).

When connecting external operating voltage for the control system with separate earth-fault breaker, disconnect the blue cable from terminal block X7:24 on the immersion heater circuit board (AA1) and connect in the enclosed top clamp together with the incoming operating zero. Connect a blue cable (min 0.75 mm²) between the top clamp and X11:N on the immersion heater circuit board (as illustrated).


Operating voltage (230VAC) is connected to AA1:X11 (as illustrated).




¹Only with separate residual current device.

SWITCHING FROM 3X400 V TO 1X230 V

F372 can be switched from 3x400 V to 1x230 V by connecting the supply to L1 and L3.



If the room sensor is used in a room with underfloor heating, it should only have an indicative function, not control of the room temperature.




OUTSIDE SENSOR

The outdoor temperature sensor (BT1) is placed in the shade on a wall facing north or north-west, so it is unaffected, for example, by the morning sun.

Connect the outdoor temperature sensor to terminal block X6:1 and X6:2 on the input board (AA3).

If a conduit is used it must be sealed to prevent condensation in the sensor capsule.



NOTE!

Changes of temperature in accommodation take time. For example, short time periods in combination with underfloor heating will not give a noticeable difference in room temperature.

ROOM SENSOR

F372 is supplied with an enclosed room sensor (BT50). The room sensor has a number of functions:

1. Shows current room temperature in the display on F372.
2. Option of changing the room temperature in °C.
3. Provides the option of fine-tuning the room temperature.


Install the sensor in a neutral position where the set temperature is wanted.

A suitable location is on a free inner wall in a hall approx. 1.5 m above the floor. It is important that the sensor is not prevented from measuring the correct room temperature, for example by being located in a recess, between shelves, behind a curtain, above or close to a heat source, in a draught from an external door or in direct sunlight. Closed radiator thermostats can also cause problems.

F372 operates without the room sensor, but if you want to read the home's indoor temperature from the display on F372, the sensor must be fitted. Connect the room sensor to X6:3 and X6:4 on the input board (AA3).

If the room temperature sensor will have a controlling function, it is activated in menu 1.9.4 - "room sensor settings".

Settings



ELECTRICAL ADDITION - MAXIMUM OUTPUT

The immersion heater's power is set in menu 5.1.12 - "internal electrical addition".

When switching from 3x400 V to 1x230 V, the immersion heater must be limited to 2 kW. Min. fuse rating 16 A.

Power steps of the immersion heater

The table(s) displays the maximum phase current for the relevant power step for the heat pump.

3x400 V

| Electrical addition (kW) | Max (A) L1 | Max (A) L2 | Max (A) L3 |
|--------------------------|------------|------------|------------|
| 0.0 | 5.3 | - | - |
| 2.0 | 5.3 | - | 8.7 |
| 4.7 | 5.3 | 11.6 | 8.7 |
| 5.6 ¹ | 5.3 | 11.6 | 11.6 |
| 8.0 | 16.9 | 11.6 | 11.6 |
| 10.3 | 16.9 | 12.7 | 20.3 |

¹ Factory setting

3x230 V

| Electrical addition (kW) | Max (A) L1 | Max (A) L2 | Max (A) L3 |
|--------------------------|------------|------------|------------|
| 0.0 | 3.9 | 3.9 | - |
| 2.0 | 3.9 | 11.2 | 8.7 |
| 4.7 | 14.0 | 11.2 | 17.6 |
| 6.7 ¹ | 14.0 | 19.6 | 25.3 |
| 8.0 | 23.6 | 23.6 | 20.1 |
| 10.0 | 23.6 | 31.1 | 28.0 |

¹ Factory setting

Current sensor

If the current sensors are connected, the heat pump monitors the phase currents and allocates the electrical steps automatically to the least loaded phase.

EMERGENCY MODE

When the heat pump is set to emergency mode (SF1 is set to Δ), only the most necessary functions are activated.

- The compressor is off and heating is managed by the immersion heater.

- The load monitor is not connected.

Power in emergency mode

The immersion heater's output in emergency mode is set with the dipswitch (S2) on the immersion heater circuit board (AA1) according to the table below.

3x400 V

| kW | 1 | 2 | 3 | 4 | 5 | 6 |
|------------------|-----|-----|-----|-----|-----|-----|
| 2.0 | off | off | off | off | off | on |
| 4.7 | off | off | off | off | on | on |
| 5.3 | off | off | on | on | on | off |
| 8.0 ¹ | on | off | on | off | on | off |
| 10.3 | on | off | on | on | on | on |


¹ Factory setting

3x230 V


| kW | 1 | 2 | 3 | 4 | 5 | 6 |
|------------------|-----|-----|-----|-----|-----|-----|
| 2.0 | off | off | on | off | off | off |
| 4.7 | off | off | off | on | on | off |
| 6.7 | off | off | on | on | on | off |
| 8.0 ¹ | on | on | off | on | off | off |
| 10.0 | on | on | off | on | on | off |

¹ Factory setting

3x400 V



3x230 V



The image shows the dip-switch (AA1-S2) in the factory setting.

Optional connections

LOAD MONITOR

Integrated load monitor

F372 is equipped with a simple form of integrated load monitor, which limits the power steps for the electric additional heat by calculating whether future power steps can be connected to the relevant phase without exceeding the current for the specified main fuse.

If the current would exceed the specified main fuse, the power step is not permitted. The size of the property's main fuse is specified in menu 5.1.12 - "internal electrical addition".

Load monitor with current sensor


When many power-consuming products are connected in the property at the same time as the compressor and/or the electric additional heat is operating, there is a risk of the property's main fuses tripping.

F372 is equipped with a load monitor that, with the help of a current sensor, controls the power steps for the electric additional heat by redistributing the power between the different phases or, alternatively, disengages the electric additional heat step-by-step if there is an overload in a phase.


Reconnection occurs when the other current consumption is reduced.

Connection and activation of current sensors

1. Install a current sensor on each incoming phase conduct- or into the electrical distribution unit. This is best done in the electrical distribution unit.
2. Connect the current sensors to a multi-core cable in an enclosure directly adjacent to the electrical distribution unit. The multi-core cable between the enclosure and F372 must have a cable area of at least 0.5 mm².



3. Connect the cable to the input board (AA3) on terminal block X4:1-4 where X4:1 is the common terminal block for the three current sensors.



4. Specify the size of the property's main fuse in menu 5.1.12 - "internal electrical addition".
5. Activate phase detection in menu 5.1.12 - "internal electrical addition". Read more about phase detection in section "Menu 5.1.12 - internal electrical addition".


CONNECTING EXTERNAL ENERGY METER



CAUTION!

Connection of external energy meter requires version 35 or later on the input board (AA3) as well as "display version" 8816 or later.

One or two energy meters (BE6, BE7) are connected to terminal block X22 and/or X23 on input board (AA3).



Activate the energy meter(s) in menu 5.2.4 and then set the desired value (energy per pulse) in menu 5.3.21.

MYUPLINK


Connect the network connected cable (straight, Cat.5e UTP) with RJ45-contact (male) to RJ45 contact (female) on the rear of the heat pump.



EXTERNAL CONNECTION OPTIONS

F372 has software-controlled AUX inputs and outputs for connecting the external switch function (contact has to be potential-free) or sensor.

In menu 5.4 - "soft in/outputs", you select the AUX connection to which each function has been connected.



For certain functions, accessories may be required.




TIP!

Some of the following functions can also be activated and scheduled via menu settings.

Selectable inputs

Selectable inputs on the input board (AA3) for these functions are:

| | |
|------|--------------|
| AUX1 | AA3-X6:9-10 |
| AUX2 | AA3-X6:11-12 |
| AUX3 | AA3-X6:13-14 |
| AUX4 | AA3-X6:15-16 |
| AUX5 | AA3-X6:17-18 |




The example above uses the inputs AUX1 (X6:9-10) and AUX2 (X6:11-12) on the input board (AA3).

Selectable outputs

A selectable output is AA3-X7.

The output is a potential-free switching relay.

When switch (SF1) is in the "U" or "Δ" position, the relay is in the alarm position.



NOTE!

The relay output may be subjected to a max load of 2 A at resistive load (230 V-).



TIP!

The AXC accessory is required if more than one function is to be connected to the AUX output.

Possible selection for AUX inputs

Monitor

Available options are:

- pressure switch for climate system (NC).
- alarm from external units.
The alarm is connected to the control, which means that the malfunction is shown as an information message in the display. Potential free signal of type NO or NC.

External activation of functions

An external switch function can be connected to F372 to activate various functions. The function is activated during the time the switch is closed.

Possible functions that can be activated:

- hot water comfort mode "temporary lux"
- hot water comfort mode "economy"
- "external adjustment"

When the switch is closed, the temperature is changed in °C (if a room sensor is connected and activated). If a room sensor is not connected or not activated, the desired change of "temperature" (heating curve offset) is set with the number of steps selected. The value is adjustable between -10 and +10. External adjustment of the climate system 2 to 8 is performed on the respective accessory boards.

- climate system 1 to 8

Setting the value for the change is performed in menu 1.9.2 - "external adjustment".

- activation of one of four fan speeds.

The following options are available:

- "activate fan speed 1 (NO)" - "activate fan speed 4 (NO)"
- "activate fan speed 1 (NC)"

The fan speed is activated during the time the switch is closed. Normal speed is resumed when the switch is opened again.

- SG ready



NOTE!

This function can only be used in mains networks that support the "SG Ready" standard.

"SG Ready" requires two AUX inputs.

"SG Ready" is a smart form of tariff control, where your electricity supplier can alter the indoor and hot water temperatures or simply block the additional heating and/or the compressor in the heat pump at certain times of the day (can be selected in menu 4.1.5 - "SG Ready" after the function is activated). Activate the function by connecting

potential free switch functions to two inputs as selected in menu 5.4 - "soft in/outputs" (SG Ready A and SG Ready B).

Closed or open switch means one of the following:

- *Blocking (A: Closed, B: Open)*
"SG Ready" is active. The compressor in the heat pump and additional heat is blocked.
- *Normal mode (A: Open, B: Open)*
"SG Ready" is not active. No effect on the system.
- *Low price mode (A: Open, B: Closed)*
"SG Ready" is active. The system focuses on costs savings and can for example exploit a low tariff from the electricity supplier or over-capacity from any own power source (effect on the system can be adjusted in the menu 4.1.5).
- *Overcapacity mode (A: Closed, B: Closed)*
"SG Ready" is active. The system is permitted to run at full capacity at over capacity (very low price) with the electricity supplier (effect on the system is settable in menu 4.1.5).

(A = SG Ready A and B = SG Ready B)

• +Adjust

Using +Adjust, the system communicates with the under floor heating's control centre¹ and adjusts the heating curve and calculated supply temperature based on the under floor heating system's feedback.

Activate the climate system you want +Adjust to affect by highlighting the function and pressing the OK button.

 **NOTE!**

This function may require a software update in your F372. The version can be checked in the menu 3.1 - "Service info". Visit myuplink.com and click on the "Software" tab to download the latest software to your installation.

 **NOTE!**

In systems with both underfloor heating and radiators, NIBE ECS 40/41 should be used for optimum operation.

External blocking of functions

An external switch function can be connected to F372 for blocking various functions. The switch must be potential-free and a closed switch results in blocking.

¹ Support for +Adjust is required



CAUTION!

Blocking entails a risk of freezing.

Functions that can be blocked:

- hot water (hot water production). Any hot water circulation (HWC) remains in operation.
- heating (blocking of heating demand)
- internally controlled additional heat
- compressor
- tariff blocking (additional heat, compressor, heating and hot water are disconnected)

Possible selections for AUX output

Indication

- alarm
- holiday
- away mode for "smart home" (complement to the functions in menu 4.1.7 - "smart home")

Control


- circulation pump for hot water circulation
- external heating medium pump



CAUTION!

The relevant distribution box must be marked with a warning about external voltage.

An external circulation pump is connected to the AUX output, as illustrated below.



Connecting accessories

Instructions for connecting accessories are provided in the manual accompanying the accessory. See page 55 for the list of the accessories that can be used with F372.

Commissioning and adjusting

Preparations

1. Check that the switch (SF1) is in position "⏻".
2. Check that the filling valves (QM10) and (QM11) are fully closed.



NOTE!

Check the miniature circuit-breaker (FC1). It could have tripped during transport.

Filling and venting

FILLING THE HOT WATER HEATER

1. Open a hot water tap in the house.
2. Open the filling valve (QM10). Afterwards, this valve must be fully open during operation.
3. When the water that comes out of the hot water tap is no longer mixed with air, the water heater is full and the tap can be closed.

FILLING THE CLIMATE SYSTEM

1. Check that the shut-off valves for the heating system (QM31) and (QM32) are open.
2. Open the vent valve (QM20).
3. Open the filling valves (QM11), (QM13). The heating unit and the rest of the climate system fill with water.
4. When the water exiting the vent valve (QM20) is no longer mixed with air, close the valve.
5. After a while, the pressure begins to rise on the pressure gauge (BP5). When the pressure reaches 2.5 bar (0.25 MPa), the safety valve (FL2) starts to release water. Now, close one filling valve (QM11).
6. Reduce the boiler pressure to the normal working range (approx. 1 bar) by opening the vent valve (QM20) or the safety valve (FL2).
7. Check that there is water in the overflow cup (WM1).

If the overflow cup requires topping up:

1. Carefully turn the safety valve for hot water (FL1) anti-clockwise.


VENTING THE CLIMATE SYSTEM

1. Turn the power switch (SF1) to ⏻.
2. Vent the heat pump via the vent valve (QM20) and the rest of the climate system via its respective vent valves.
3. Keep topping up and venting until all air has been removed and the pressure is correct.



CAUTION!

The vent pipe from the container must be drained of water before air can be released. This means that the system is not necessarily bled despite the flow of water when the bleed valve (QM20) is opened.



Start-up and inspection

START GUIDE



CAUTION!

There must be water in the climate system before the switch is set to "I".



CAUTION!

Do not start F372 if there is a risk that the water in the system has frozen.

1. Set switch (SF1) on F372 to position "I".
2. Follow the instructions in the display's start guide. If the start guide does not start when you start the F372, you can start it manually in menu 5.7.



TIP!

See page 39 for a more in-depth introduction to the heat pump's control system (operation, menus etc.).

Commissioning

The first time the installation is started a start guide is started. The start guide instructions state what needs to be carried out at the first start together with a run through of the installation's basic settings.

The start guide ensures that the start-up is carried out correctly and, for this reason, cannot be skipped.



NOTE!


As long as the start guide is active, no function in the installation will start automatically.

The start guide will appear at each restart of the installation, until it is deselected on the last page.

Operation in the start guide

A. Page

B. Name and menu number



C. Option / setting

A. Page

Here you can see how far you have come in the start guide.

Scroll between the pages of the start guide as follows:

1. Turn the control knob until one of the arrows in the top left corner (at the page number) has been marked.
2. Press the OK button to skip between the pages in the start guide.

B. Name and menu number

Here, you can see which menu in the control system this page of the start guide is based on. The digits in brackets refer to the menu number in the control system.

If you want to read more about affected menus either consult the help menu or read the user manual.

C. Option / setting

Make settings for the system here.

SETTING THE VENTILATION

The ventilation must be set according to applicable standards. The fan speed is set in menu 5.1.5 - "fan speed".

Even if ventilation is roughly set at installation it is important that a ventilation adjustment is ordered and permitted.




CAUTION!

Order a ventilation adjustment to complete the setting.


Ventilation capacity

Available pressure
(Pa)



Fan rating

Output
(w)



COMMISSIONING WITHOUT FAN

The heat pump can be run without recovery, as only an electric boiler, to produce heat and hot water, for example before the ventilation installation is complete.


1. Enter menu 4.2 - "op. mode" and select "add. heat only"
2. Enter menu 5.1.5 - "fan sp. exhaust air" and reduce the fan speed to 0%.




CAUTION!

Select operating mode "auto" or "manual" when the heat pump is to run on recovery again.

SETTING CIRCULATION PUMP



The circulation pump (GP1) is equipped with five LEDs. In normal mode, the LEDs show the pump's setting by lighting up in green and/or yellow. The LEDs can also indicate an alarm, in which case they light up in red and yellow.



The circulation pump's (GP1) various settings are selected by pressing the switch (GP1-SF4).

Choose between 5 different settings on the circulation pump.

- proportional pressure auto adapt (PPAA)
- constant pressure auto adapt (CPAA)
- proportional pressure (PP)
- constant pressure (CP)
- constant curve (CC).


The circulation pump's factory setting is CP, speed 3.

Proportional pressure auto adapt (PPAA)


The circulation pump continually regulates the flow through the system with a great deal of freedom, to ensure minimum pump power consumption.

The setting is intended for radiator systems. Due to optimisation to low pumping capacity, the flow may be insufficient in certain systems.

Capacity, circulation pump (PPAA)



Power, circulation pump (PPAA)




| Setting PPAA | |
|----------------|--|
| LED indication | |

Constant pressure auto adapt (CPAA)


The circulation pump continually regulates the flow through the system with a great deal of freedom, to ensure minimum pump power consumption.

The setting is intended for underfloor heating systems. Due to optimisation to low pumping capacity, the flow may be insufficient in certain systems.

Capacity, circulation pump (CPAA)



Power, circulation pump (CPAA)




| Setting CPAA | |
|----------------|--|
| LED indication | |

Proportional pressure (PP)


Within a limited range, the circulation pump is permitted to regulate its speed to an optimum system pressure. Speed 1, 2 or 3 is selected based on maximum flow requirement.

The setting is intended for radiator systems.

Capacity, circulation pump (PP)



Output, circulation pump (PP)




| Pump speed PP | 1 | 2 | 3 |
|----------------|---|---|---|
| LED indication | | | |

Constant pressure (CP)

Within a limited range, the circulation pump is permitted to regulate its speed to a constant system pressure. Speed 1, 2 or 3 is selected based on maximum flow requirement.

The setting is intended for underfloor heating systems.

Capacity, circulation pump (CP)




Constant curve (CC)


The circulation pump's speed is fixed and no regulation takes place. Speed is selected based on maximum flow requirement.

The setting can be used when very high flows are required.


Capacity, circulation pump (CC)



Output, circulation pump (CP)



Output, circulation pump (CC)



| Pump speed CP | 1 | 2 | 3 1 |
|----------------|---|---|-----|
| LED indication | | | |

| Pump speed CC | 1 | 2 | 3 |
|----------------|---|---|---|
| LED indication | | | |

1 The circulation pump's factory setting

Alarm

If an alarm occurs, LED  shines red.

When one or more alarms are active, this is indicated according to the following table. If more than one alarm is active, the one with the highest priority is displayed.

| Cause / Action | |
|---|---|
| The rotor is blocked. Wait or release the rotor shaft. |  |
| Supply voltage too low. Check the supply voltage. |  |
| Electrical fault. Check the supply voltage or replace the circulation pump. |  |


Setting the heating curve

In the menu "heating curve", you can see the heating curve for your house. The task of the curve is to provide an uniform indoor temperature, regardless of the outdoor temperature, and thereby energy-efficient operation. Based on this curve, the F372 determines the temperature of the water to the climate system (the supply temperature) and thus the indoor temperature.

CURVE COEFFICIENT

The slope of the heating curve indicates how many degrees the supply temperature is to be increased/reduced when the outdoor temperature drops/increases. A steeper slope means a higher supply temperature at a certain outdoor temperature.

The lower the heating curve, the more energy efficient the operation, although an excessively low curve entails reduced comfort.




The optimum curve slope depends on the climate conditions and the lowest dimensioned outdoor temperature (DOT) in your location, whether the house has radiators, fan coils or underfloor heating and how well insulated the house is.

For houses with radiators or fan coils, a higher heating curve (e.g. curve 9) is suitable, for houses with under floor heating, a lower curve (e.g. curve 5) is suitable.

The heating curve is set when the heating installation is installed, but may need adjusting later. Normally, the curve will not need further adjustment.


CURVE OFFSET

An offset of the heating curve means that the supply temperature changes by the same amount for all outdoor temperatures, e.g. a curve offset of +2 steps increases the supply temperature by 5 °C at all outdoor temperatures.



SUPPLY TEMPERATURE - MAXIMUM AND MINIMUM VALUES


Because the flow line temperature cannot be calculated higher than the set maximum value or lower than the set minimum value the heating curve flattens out at these temperatures.



NOTE!

With underfloor heating systems, the maximum supply temperature is normally set between 35 and 45 °C.

ADJUSTMENT OF CURVE



1. Select the climate system (if more than one) for which the curve is to be changed.
2. Select curve slope and curve offset.



NOTE!

If you need to adjust "min. flow line temp." and/or "max flow line temperature", you do this in other menus.

Settings for "min. flow line temp." in menu 1.9.3.

Settings for "max flow line temperature" in menu 5.1.2.



NOTE!

Curve 0 means that "own curve" is used.

Settings for "own curve" are made in menu 1.9.7.

TO READ OFF A HEATING CURVE

1. Turn the control knob so that the ring on the shaft with the outdoor temperature is marked.
2. Press the OK button.
3. Follow the grey line up to the curve and out to the left to read off the value for the supply temperature at the selected outdoor temperature.
4. You can now select to take read outs for different outdoor temperatures by turning the control knob to the right or left and read off the corresponding flow temperature.
5. Press the OK or Back button to exit read off mode.

myUplink

With myUplink you can control the installation – where and when you want. In the event of any malfunction, you receive an alarm directly to your e-mail or a push notification to the myUplink app, which allows you to take prompt action.

Visit myuplink.com for more information.

Update your system to the latest software version.

Specification

You need the following in order for myUplink to be able to communicate with your F372:

- network cable
- Internet connection
- account on myuplink.com

We recommend our mobile apps for myUplink.

Connection

To connect your system to myUplink:

1. Select connection type (wifi/Ethernet) in menu 4.1.3 – internet.
2. Mark “request new connection string” and press the OK button.
3. When a connection string has been produced, it is shown in this menu and is valid for 60 minutes.
4. If you do not already have an account, register in the mobile app or on myuplink.com.
5. Use the connection string to connect your installation to your user account on myUplink.

Range of services

myUplink gives you access to various levels of service. The base level is included and, apart from this, you can choose two premium services for a fixed annual fee (the fee varies depending on the functions selected).

| Service level | Basic | Premium extended history | Premium change settings |
|------------------|-------|--------------------------|-------------------------|
| Viewer | X | X | X |
| Alarm | X | X | X |
| History | X | X | X |
| Extended history | - | X | - |
| Manage | - | - | X |

myUplink PRO


myUplink PRO is a complete tool for offering service agreements to the end customer and for always having the latest information about the installation, as well as the option to adjust settings remotely.

With myUplink PRO, you can provide your connected customers with rapid status and remote diagnostics.

Visit pro.myuplink.com for information about what else you can do using the mobile app and online.

Control - Introduction


Display unit



- A DISPLAY**
Instructions, settings and operational information are shown on the display. You can easily navigate between the different menus and options to set the comfort or obtain the information you require.
- B STATUS LAMP**
The status lamp indicates the status of the heat pump. It:
- lights green during normal operation.
 - lights yellow in emergency mode.
 - lights red in the event of a deployed alarm.
- C OK BUTTON**
The OK button is used to:
- confirm selections of sub menus/options/set values/page in the start guide.
- D BACK BUTTON**
The back button is used to:
- go back to the previous menu.
 - change a setting that has not been confirmed.
- E CONTROL KNOB**
The control knob can be turned to the right or left. You can:
- scroll in menus and between options.
 - increase and decrease the values.
 - change page in multiple page instructions (for example help text and service info).
- F SWITCH (SF1)**
The switch assumes three positions:
- On (I)
 - Standby (U)
 - Emergency mode (Δ) (see page 49)
- Emergency mode must only be used in the event of a fault on the heat pump. In this mode, the compressor switches off and the immersion heater engages. The heat pump display is not illuminated and the status lamp illuminates yellow.
- G USB PORT**
The USB port is hidden beneath the plastic badge with the product name on it.
The USB port is used to update the software.
Visit myuplink.com and click the "Software" tab to download the latest software for your installation.

Menu system

When the door to the heat pump is opened, the menu system's four main menus are shown in the display as well as certain basic information.




- MENU 1 - INDOOR CLIMATE**
Setting and scheduling the indoor climate. See information in the help menu or user manual.
- MENU 2 - HOT WATER**
Setting and scheduling hot water production. See information in the help menu or user manual.
- MENU 3 - INFO**
Display of temperature and other operating information and access to the alarm log. See information in the help menu or user manual.
- MENU 4 - HEAT PUMP**
Setting time, date, language, display, operating mode etc. See information in the help menu or user manual.
- MENU 5 - SERVICE**
Advanced settings. These settings are not available to the end user. The menu is visible when the Back button is pressed for 7 seconds when you are in the start menu. See page 45.

SYMBOLS IN THE DISPLAY

The following symbols may appear on the display during operation.

| Symbol | Description |
|---|--|
|  | This symbol appears by the information sign if there is information in menu 3.1 that you should note. |
|  | <p>These two symbols indicate whether the compressor or addition is blocked in F372.</p> <p>These can, for example, be blocked depending on which operating mode is selected in menu 4.2, if blocking is scheduled in menu 4.9.5 or if an alarm has occurred that blocks one of them.</p> <p> Blocking the compressor.</p> <p> Blocking additional heat.</p> |
|  | This symbol appears if periodic increase or lux mode for the hot water is activated. |
|  | This symbol indicates whether "holiday setting" is active in 4.7. |
|  | This symbol indicates whether F372 has contact with myUplink. |
|  | This symbol indicates the actual speed of the fan if the speed has changed from the normal setting. |
|  | This symbol is visible in installations with active solar accessories. |



OPERATION

To move the cursor, turn the control knob to the left or the right. The marked position is white and/or has a turned up tab.



SELECTING MENU

To advance in the menu system select a main menu by marking it and then pressing the OK button. A new window then opens with sub menus.


Select one of the sub menus by marking it and then pressing the OK button.

SETTING A VALUE



Values to be changed

SELECTING OPTIONS



Alternative

In an options menu the current selected option is indicated by a green tick. 


To select another option:

1. Mark the applicable option. One of the options is pre-selected (white). 
2. Press the OK button to confirm the selected option. The selected option has a green tick. 


To set a value:

1. Mark the value you want to set using the control knob. 01
2. Press the OK button. The background of the value becomes green, which means that you have accessed the setting mode. 01
3. Turn the control knob to the right to increase the value and to the left to reduce the value. 04
4. Press the OK button to confirm the value you have set. To change and return to the original value, press the Back button. 04

USE THE VIRTUAL KEYBOARD




In some menus where text may require entering, a virtual keyboard is available.



Depending on the menu, you can gain access to different character sets which you can select using the control knob. To change character table, press the Back button. If a menu only has one character set the keyboard is displayed directly. When you have finished writing, mark "OK" and press the OK button.

SCROLL THROUGH THE WINDOWS

A menu can consist of several windows. Turn the control knob to scroll between the windows.



Scroll through the windows in the start guide



Arrows to scroll through window in start guide

1. Turn the control knob until one of the arrows in the top left corner (at the page number) has been marked.
2. Press the OK button to skip between the steps in the start guide.

HELP MENU

 In many menus there is a symbol that indicates that extra help is available.

To access the help text:

1. Use the control knob to select the help symbol.
2. Press the OK button.

The help text often consists of several windows that you can scroll between using the control knob.

Control - Menus

Menu 1 - INDOOR CLIMATE

OVERVIEW

| | | |
|--------------------|-----------------------|------------------------------|
| 1 - INDOOR CLIMATE | 1.1 - temperature | |
| | 1.2 - ventilation | |
| | 1.3 - scheduling | 1.3.1 - heating |
| | | 1.3.3 - ventilation |
| | 1.9 - advanced | 1.9.1.1 - heating curve |
| | | 1.9.2 - external adjustment |
| | | 1.9.3 - min. flow line temp. |
| | | 1.9.4 - room sensor settings |
| | | 1.9.6 - fan return time |
| | | 1.9.7 - own curve |
| | 1.9.8 - point offset | |
| | 1.9.9 - night cooling | |

Menu 2 - HOT WATER

OVERVIEW

| | | |
|---------------|---------------------|-----------------------------|
| 2 - HOT WATER | 2.1 - temporary lux | |
| | 2.2 - comfort mode | |
| | 2.3 - scheduling | |
| | 2.9 - advanced | 2.9.1 - periodic increase |
| | | 2.9.2 - hot water recirc. * |

* Accessory needed.

Menu 3 - INFO

OVERVIEW

| | |
|----------|------------------------|
| 3 - INFO | 3.1 - service info |
| | 3.2 - compressor info |
| | 3.3 - add. heat info |
| | 3.4 - alarm log |
| | 3.5 - indoor temp. log |
| | 3.6 - energy log |

Menu 4 - HEAT PUMP

OVERVIEW

| | | | |
|---------------|------------------------|-----------------------------------|---------------------------|
| 4 - HEAT PUMP | 4.1 - plus functions * | 4.1.3 - internet | 4.1.3.1 - myUplink |
| | | | 4.1.3.8 - tcp/ip settings |
| | | | 4.1.3.9 - proxy settings |
| | | 4.1.5 - SG Ready | |
| | | 4.1.6 - smart price adaption™ | |
| | | 4.1.7 - smart home | |
| | | Menu 4.1.10 - solar electricity * | |
| | 4.2 - op. mode | | |
| | 4.4 - time & date | | |
| | 4.6 - language | | |
| | 4.7 - holiday setting | | |
| | 4.9 - advanced | 4.9.2 - auto mode setting | |
| | | 4.9.4 - factory setting user | |
| | | 4.9.5 - schedule blocking | |

* Accessory needed.

Menu 5 - SERVICE

OVERVIEW

| | | |
|-------------|-------------------------------|---------------------------------------|
| 5 - SERVICE | 5.1 - operating settings | 5.1.1 - hot water settings |
| | | 5.1.2 - max flow line temperature |
| | | 5.1.4 - alarm actions |
| | | 5.1.5 - fan sp. exhaust air |
| | | 5.1.12 - internal electrical addition |
| | | 5.1.99 - other settings |
| | 5.2 - system settings | 5.2.4 - accessories |
| | 5.3 - accessory settings | 5.3.3 - extra climate system * |
| | | 5.3.21 - flow sensor / energy meter* |
| | 5.4 - soft in/outputs | |
| | 5.5 - factory setting service | |
| | 5.6 - forced control | |
| | 5.7 - start guide | |
| | 5.8 - quick start | |
| | 5.9 - floor drying function | |
| | 5.10 - change log | |
| | 5.12 - country | |

* Accessory needed.

Go to the main menu and hold the Back button in for 7 seconds to access the Service menu.

Sub-menus

Menu **SERVICE** has orange text and is intended for the advanced user. This menu has several sub-menus. Status information for the relevant menu can be found on the display to the right of the menus.

operating settings Operating settings for the heat pump.

system settings System settings for the heat pump, activating accessories etc.

accessory settings Operational settings for different accessories.

soft in/outputs Setting software-controlled inputs and outputs on input board (AA3).

factory setting service Total reset of all settings (including settings available to the user) to default values.

forced control Forced control of the different components in the heat pump.

start guide Manual start of the start guide which is run the first time the heat pump is started.

quick start Quick starting the compressor.



CAUTION!

Incorrect settings in the service menus can damage the heat pump.

MENU 5.1.1 - HOT WATER SETTINGS



CAUTION!

The factory set tap water temperatures specified in the manual can vary due to the directives in force in different countries. From this menu, you can check the relevant settings for the system.

MENU 5.1 - OPERATING SETTINGS

Operating settings can be made for the heat pump in the sub menus.

economy

Setting range start temp. economy: 15 - 52 °C

Factory setting start temp. economy: 45 °C

Setting range stop temp. economy: 15 - 55 °C

Factory setting stop temp. economy: 51 °C

normal

Setting range start temp. normal: 15 - 52 °C

Factory setting start temp. normal: 49 °C

Setting range stop temp. normal: 15 - 55 °C

Factory setting stop temp. normal: 55 °C

large

Setting range, start temp. large: 15 - 56 °C

Factory setting, start temp. large: 53 °C

Setting range, stop temp. large: 15 - 59 °C

Factory setting, stop temp. large: 59 °C

luxury

Setting range start temp. lux: 15 - 62 °C

Factory setting start temp. lux: 53 °C

Setting range stop temp. lux: 15 - 65 °C

Factory setting stop temp. lux: 59 °C

stop temp. per. increase

Setting range: 55 - 70 °C

Factory setting: 60 °C

Here you set the start and stop temperature of the hot water for the different comfort options in menu 2.2 as well as the stop temperature for periodic increase in menu 2.9.1.

MENU 5.1.2 - MAX FLOW LINE TEMPERATURE

climate system

Setting range: 20-70 °C

Default value: 60 °C

Here, you set the maximum supply temperature for the climate system. If the installation has more than one climate system, individual maximum supply temperatures can be set for each system. Climate system 2 - 8 cannot be set to a higher max supply temperature than climate system 1.

NOTE!

For underfloor heating systems, max flow line temperature should normally be set to between 35 and 45°C.

Check the max floor temperature with your floor supplier.

MENU 5.1.4 - ALARM ACTIONS

Select if you want the heat pump to alert you that there is an alarm in the display here.

NOTE!

If no alarm action is selected, it can result in higher energy consumption in the event of an alarm.

MENU 5.1.5 - FAN SP. EXHAUST AIR

normal and speed 1-4

Setting range: 0 - 100 %

Set the speed for the five different selectable speeds for the fan here.

NOTE!

An incorrectly set ventilation flow can damage the house and may also increase energy consumption.

MENU 5.1.12 - INTERNAL ELECTRICAL ADDITION

set max electrical add.

Setting range 3x400 V: 0 - 10.3 kW

Setting range 3x230 V: 0 - 12.0 kW

Factory setting 3x400 V: 5.6 kW

Factory setting 3x230 V: 6.7 kW

fuse size

Setting range: 1 - 200 A

Factory setting: 16 A

transformation ratio

Setting range: 300 - 3000

Factory setting: 300

Here you set the max. electrical output of the internal electrical addition in F372 and the fuse size for the installation.

"detect phase order": Here, you also check which current sensor is installed on which incoming phase to the property (this only applies if you have current sensors installed, see page 26). Check by selecting "detect phase order" and pressing the OK button.

The results of these checks appear just below the menu selection "detect phase order".

TIP!

Search again if the phase detection fails. The detection process is very sensitive and is easily affected by other appliances in the accommodation.

"transformation ratio": The transformer ratio can be changed to match different types of current sensor. The factory setting is adjusted according to the enclosed current sensors.

MENU 5.1.99 - OTHER SETTINGS

trend calculation limit

Setting range: 0 – 20 °C

Default value: 7 °C

transfer time

Setting range: 1 – 60 min

Factory setting: 45 min

months btwn filter alarms

Setting range: 1 – 12

Default value: 3

Here you can set trend calculation limit, transfer time, months btwn filter alarms and fan synch. operation .

trend calculation limit

Here you set at what outdoor temperature the trend calculation is to be active. Above this limit, connection of the immersion heater is delayed and the immersion heater is not connected if the compressor is able to increase the temperature in the vessel.

transfer time

Here you can set transfer time between heating and hot water production in F372. During the transfer time the compressor maintains the stop temperature that applied during hot water production.

months btwn filter alarms

Here you set the number of months between alarms for a reminder to clean the filter in F372.

fan synch. operation

Select whether the fan is to maintain the same speed, regardless of whether the compressor is operating or not, or alternatively run at different speeds. If the function is activated, fan speed 2 applies when the compressor is not in operation, and normal fan speed applies when the compressor is in operation.

MENU 5.2 - SYSTEM SETTINGS

Make different system settings for the heat pump here, e.g. which accessories are installed.

MENU 5.2.4 - ACCESSORIES

Inform the heat pump which accessories are installed here.

There are two ways of activating connected accessories. You can either mark the alternative in the list or use the automatic function "search installed acc."

search installed acc.

Mark "search installed acc." and press the OK button to automatically find connected accessories for F372.

MENU 5.3 - ACCESSORY SETTINGS

The operating settings for accessories that are installed and activated are made in the sub-menus for this.

MENU 5.3.3 - EXTRA CLIMATE SYSTEM

mixing valve amplifier

Setting range: 0.1 – 10.0

Default value: 1.0

mixing valve step delay

Setting range: 10 – 300 s

Default values: 30 s

Contr. pump GP10

Setting range: on/off

Factory setting: off

Here, you select which climate system (2 - 8) you wish to set.

mixing valve amplifier, mixing valve step delay: Here, you set the shunt amplification and shunt waiting time for the various extra climate systems that are installed.

Contr. pump GP10: Here, you can set the speed of the circulation pump manually.

See the accessory installation instructions for function description.

MENU 5.3.21 - FLOW SENSOR / ENERGY METER

Energy meter

set mode

Setting range: energy per pulse / pulses per kWh

Default value: energy per pulse

energy per pulse

Setting range: 0 – 10000 Wh

Factory setting: 1000 Wh

pulses per kWh

Setting range: 1 – 10000

Factory setting: 500

Energy meter (Electricity meter)

The energy meter(s) is used to send pulse signals every time a certain amount of energy has been consumed.

energy per pulse: Here you set the amount of energy to which each pulse will correspond.

pulses per kWh: Here you set the number of pulses per kWh that are sent to F372.

MENU 5.4 - SOFT IN/OUTPUTS

Here, you can select which input/output on the input board (AA3) the external switch function (page 27) will be connected to.

Selectable inputs on terminal block AUX 1-5 (AA3-X6:9-18) and output AA3-X7 on the input board.

MENU 5.5 - FACTORY SETTING SERVICE

All settings can be reset (including settings available to the user) to default values here.

NOTE!

When resetting, the start guide is displayed the next time the heat pump is restarted.

MENU 5.6 - FORCED CONTROL

You can force control the different components in the heat pump and any connected accessories here.

MENU 5.7 - START GUIDE

When the heat pump is started for the first time the start guide starts automatically. Start it manually here.

See page 31 for more information about the start guide.

MENU 5.8 - QUICK START

It is possible to start the compressor from here.

NOTE!

There must be a heating or hot water demand to start the compressor.

CAUTION!

Do not quick start the compressor too many times over a short period of time, as this could damage the compressor and its surrounding equipment.

MENU 5.9 - FLOOR DRYING FUNCTION

length of period 1 - 7

Setting range: 0 - 30 days

Factory setting, period 1 - 3, 5 - 7: 2 days

Factory setting, period 4: 3 days

temp. period 1 - 7

Setting range: 15 - 70 °C

Default value:

| | |
|----------------|-------|
| temp. period 1 | 20 °C |
| temp. period 2 | 30 °C |
| temp. period 3 | 40 °C |
| temp. period 4 | 45 C |
| temp. period 5 | 40 °C |
| temp. period 6 | 30 °C |
| temp. period 7 | 20 °C |

Set the function for under floor drying here.

You can set up to seven time periods with different calculated supply temperatures. If fewer than seven periods are to be used, set the remaining periods to 0 days.

Mark the active window to activate the underfloor drying function. A counter at the bottom shows the number of days the function has been active.

TIP!

If operating mode "add. heat only" is to be used, select it in menu 4.2.

TIP!

It is possible to save a floor drying log that shows when the concrete slab has reached the correct temperature. See section "Logging floor drying" on page 51.

MENU 5.10 - CHANGE LOG

Read off any previous changes to the control system here.

The date, time, ID no. (unique to particular setting) and the new set value are shown for every change.

NOTE!

The change log is saved at restart and remains unchanged after factory setting.

5.12 - COUNTRY

Select here the country in which the product was installed. This allows access to country-specific settings in your product.

Language settings can be made regardless of this selection.

NOTE!

This option locks after 24 hours, after restarting the display and during program updating.

Service



CAUTION!

Servicing and maintenance should only be carried out by persons with the necessary expertise.

When replacing components on F372 only replacement parts from NIBE may be used.

Maintenance

Inform the user of necessary maintenance action.

CLEANING THE OVERFLOW CUP/FLOOR DRAIN

Condensation forms when the heat pump is working. This condensation is routed via an overflow cup (WM1) to a drain, e.g. a floor drain.

The condensation water contains a certain amount of dust and particles.

Regularly check that the overflow cup (WM1) and any floor drain are not blocked; water must be able to run through freely. Clean, if necessary.



CAUTION!

If the overflow cup or floor drain is blocked, water can flow over onto the floor in the installation area. To prevent damage to the building, a waterproof floor or floor membrane is recommended.


Service actions

EMERGENCY MODE

Emergency mode is used in event of operational interference and in conjunction with service.

Emergency mode is activated by setting switch (SF1) to "△". This means that:

- The status lamp illuminates yellow.
- The display is not lit and the control computer is not connected.
- The temperature in the heating section is controlled by a fixed thermostat (BT30) at 63 °C.
- The compressor is switched off and only the fan, the heating medium pump and the electric additional heat are active. The electric additional heat power in emergency mode is set on the electric addition PCB (AA1). See page 26 for instructions.
- The automatic heating control system is not operational, so manual mixing is required. This is done by turning the adjustment screw on the shunt motor (MA1) to "manual mode" and then turning the shunt knob to the desired position.



DRAINING THE HOT WATER HEATER

The hot water can be drained as follows:

- through the safety valve (FL1) via the overflow cup (WM1)
- through a hose that is connected to the safety valve's (FL1) outlet



CAUTION!

There may be some hot water, risk of scalding.

Draining with hose via the safety valve:

1. Disconnect the overflow pipe from the safety valve (FL1).
2. Fit a hose to a drain pump.
3. Open the safety valve (FL1).
4. Open a hot water tap to let air into the system. If this is not enough, disconnect the hot water connection (XL4).

DRAINING THE CLIMATE SYSTEM

In order to carry out service on the climate system, it may be easier to drain the system first.



CAUTION!

There may be some hot water, risk of scalding.

The hot water can be drained as follows:


- through the safety valve (FL2) via the overflow cup (WM1)
 - through a hose that is connected to the safety valve's (FL2) outlet
1. Open the safety valve.
 2. Set the vent valve for the climate system (QM20) in the open position for air supply.

HELPING THE CIRCULATION PUMP TO START


The circulation pump in F372 has an automatic start help function. If necessary the pump can be started manually. In such cases, take the following action:

1. Turn off F372 by setting the switch (SF1) to "⏻".
2. Remove the front cover

3. Press in the screw for start help using a screwdriver as illustrated.
4. With the screw pressed in, turn the screwdriver in any direction.
5. Start F372 by setting the switch (SF1) to "I", and check that the circulation pump is working.





USB SERVICE OUTLET



The display unit is equipped with a USB socket that can be used to update the software and save logged information in F372.


TEMPERATURE SENSOR DATA

| Temperature (°C) | Resistance (kOhm) | Voltage (VDC) |
|------------------|-------------------|---------------|
| -10 | 56.20 | 3.047 |
| 0 | 33.02 | 2.889 |
| 10 | 20.02 | 2.673 |
| 20 | 12.51 | 2.399 |
| 30 | 8.045 | 2.083 |
| 40 | 5.306 | 1.752 |
| 50 | 3.583 | 1.426 |
| 60 | 2.467 | 1.136 |
| 70 | 1.739 | 0.891 |
| 80 | 1.246 | 0.691 |



When a USB memory is connected, a new menu (menu 7) appears in the display.

Menu 7.1 - "update firmware"



Here, you can update the software in F372.



CAUTION!

For the following functions to work the USB memory must contain files with software for F372 from NIBE.

The fact box at the top of the display shows information (always in English) of the most probable update that the update software has selected from the USB memory.

This information states the product for which the software is intended, the software version and general information about it. If you want a file other than the one selected, the correct file can be selected through "choose another file".

start updating

Select "start updating" if you want to start the update. You are asked whether you really want to update the software. Respond "yes" to continue or "no" to undo.

If you responded "yes" to the previous question the update starts and you can now follow the progress of the update on the display. When the update is complete F372 restarts.



TIP!


A software update does not reset the menu settings in F372.



NOTE!


If the update is interrupted before it is complete (for example, by a power cut), the software can be reset to the previous version if the OK button is held in during start-up until the green lamp comes on (takes about 10 seconds).

choose another file



Select "choose another file" if you do not want to use the suggested software. When you scroll through the files, information about the marked software is shown in a fact box just as before. When you have selected a file with the OK button you will return to the previous page (menu 7.1) where you can choose to start the update.

Menu 7.2 - logging



Setting range: 1 s – 60 min

Factory setting range: 5 s

Here you can choose how current measurement values from F372 should be saved onto a log file on the USB memory.

1. Set the desired interval between loggings.
2. Tick "activated".
3. The present values from F372 are saved in a file in the USB memory at the set interval until "activated" is unticked.



NOTE!

Untick "activated" before removing the USB memory.

Logging floor drying

Here you can save a floor drying log on the USB memory and in this way see when the concrete slab reached the correct temperature.


- Make sure that "floor drying function" is activated in menu 5.9.
- Select "logging floor drying activated".
- A log file is now created, where the temperature and the immersion heater output can be read off. Logging continues until "logging floor drying activated" is deselected or until "floor drying function" is stopped.



NOTE!

Deselect "logging floor drying activated" before you remove the USB memory.

Menu 7.3 - manage settings



save settings

Setting option: on/off

recover settings

Setting option: on/off

In this menu, you save/upload menu settings to/from a USB memory stick.

save settings: Here, you save menu settings in order to restore them later or to copy the settings to another F372.



NOTE!

When you save menu settings to the USB memory, you replace any previously saved settings on the USB memory.

recover settings: Here, you upload all menu settings from the USB memory stick.



NOTE!

Resetting of menu settings from the USB memory cannot be undone.

Disturbances in comfort

In most cases, F372 notes a malfunction (a malfunction can lead to disruption in comfort) and indicates this with alarms, and instructions for action, in the display.

Info menu

All the heat pump measurement values are gathered under menu 3.1 in the heat pump menu system. Looking through the values in this menu can often simplify finding the source of the fault. See help menu or user manual for more information about menu 3.1.

Manage alarm



In the event of an alarm, some kind of malfunction has occurred, which is indicated by the status lamp changing from green continuously to red continuously. In addition, an alarm bell appears in the information window.

ALARM

In the event of an alarm with a red status lamp, a malfunction has occurred that the heat pump cannot remedy itself. By turning the control knob and pressing the OK button, you can see in the display what type of alarm it is and reset it. You can also choose to set the heat pump to aid mode.

info / action Here you can read what the alarm means and receive tips on what you can do to correct the problem that caused the alarm.

reset alarm In many cases, it is sufficient to select "reset alarm" for the product to revert to normal operation. If a green light comes on after selecting "reset alarm", the alarm has been remedied. If the red light is still on, and a menu called "alarm" is visible in the display, the problem causing the alarm still remains.

aid mode "aid mode" is a type of emergency mode. This means that the heat pump produces heat and/or hot water even though there is some kind of problem. This could mean that the heat pump's compressor is not running. In this case, the immersion heater produces heat and/or hot water.

NOTE!

To select aid mode an alarm action must be selected in the menu 5.1.4.



NOTE!

Selecting "aid mode" is not the same as correcting the problem that caused the alarm. The status lamp will therefore continue to be red.

Troubleshooting

If the operational interference is not shown in the display the following tips can be used:

BASIC ACTIONS

Start by checking the following items:

- The switch's (SF1) position.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.
- The heat pump's RCD.
- Miniature circuit-breaker for F372 (FC1).
- Temperature limiter for F372 (FQ10).
- Correctly set load monitor.

LOW HOT WATER TEMPERATURE OR A LACK OF HOT WATER

- Closed or choked filling valve (QM10) for the hot water.
 - Open the valve.
- Mixer valve set too low.
 - Adjust the mixer valve.
- F372 in incorrect operating mode.
 - Enter menu 4.2. If mode "auto" is selected, select a higher value on "stop additional heat" in menu 4.9.2.
 - If mode "manual" is selected, select "addition".
- Large hot water consumption.
 - Wait until the hot water has heated up. Temporarily increased hot water capacity (temporary lux) can be activated in menu 2.1.
- Too low hot water setting.
 - Enter menu 2.2 - "comfort mode" and select a higher comfort mode.

LOW ROOM TEMPERATURE

- Closed thermostats in several rooms.
 - Set the thermostats to max, in as many rooms as possible. Adjust the room temperature via menu 1.1, instead of choking the thermostats.
- See the "Saving tips" section in the User manual for more detailed information about how to best set the thermostats.
- F372 in incorrect operating mode.

- Enter menu 4.2. If mode "auto" is selected, select a higher value on "stop heating" in menu 4.9.2.
- If mode "manual" is selected, select "heating". If this is not enough, select "addition".
- Too low set value on the automatic heating control.
 - Enter menu 1.1 - "temperature" and adjust the offset heating curve up. If the room temperature is only low in cold weather, the curve slope in menu 1.9.1 - "heating curve" may need to be adjusted upwards.
- "Holiday mode" activated in menu 4.7.
 - Enter menu 4.7 and select "Off".
- External switch for changing room temperature activated.
 - Check any external switches.
- The heating medium pump (GP1 has stopped).
 - See section "Helping the circulation pump to start" on page 49.
- Air in the climate system.
 - Vent the climate system (see page 30).
- Closed valves (QM31), (QM32) to the climate system.
 - Open the valves.

HIGH ROOM TEMPERATURE

- Too high set value on the automatic heating control.
 - Enter menu 1.1 - "temperature" and reduce the offset heating curve. If the room temperature is only high in cold weather, the curve slope in menu 1.9.1 - "heating curve" may need to be adjusted downwards.
- External switch for changing room temperature activated.
 - Check any external switches.

LOW SYSTEM PRESSURE

- Not enough water in the climate system.
 - Top up the water in the climate system (see page 30).

LOW OR A LACK OF VENTILATION

- The exhaust air filter (HQ10) is clogged.
 - Clean or replace the filter.
- The ventilation is not adjusted.
 - Order/implement ventilation adjustment.
- Exhaust air device blocked or throttled down too much.
 - Check and clean the exhaust air devices.
- Fan speed in reduced mode.
 - Enter menu 1.2 - "ventilation" and select "normal"
- External switch for changing the fan speed activated.
 - Check any external switches.

HIGH OR DISTRACTING VENTILATION

- The exhaust air filter (HQ10) is clogged.
 - Clean or replace the filter.

- The ventilation is not adjusted.
 - Order/implement ventilation adjustment.
- Fan speed in forced mode.
 - Enter menu 1.2 - "ventilation" and select "normal"
- External switch for changing the fan speed activated.
 - Check any external switches.

THE COMPRESSOR DOES NOT START

- There is no heating or hot water demand.
 - F372 does not call on heating or hot water.
- The heat pump defrosts.
 - The compressor starts, when defrosting is complete.
- Compressor blocked due to the temperature conditions.
 - Wait until the temperature is within the product's working range.
- Minimum time between compressor starts has not been reached.
 - Wait for at least 30 minutes and then check if the compressor has started.
- Alarm tripped.
 - Follow the display instructions.

Accessories

Detailed information about the accessories and complete accessories list available at nibe.eu.

Not all accessories are available on all markets.

EXTRA SHUNT GROUP ECS

This accessory is used when F372 is installed in houses with two or more different climate systems that require different supply temperatures.

ECS 40

Max 80 m²

Part no 067 287

ECS 41

Approx. 80-250 m²

Part no 067 288

ROOM UNIT RMU 40

The room unit is an accessory with a built-in room sensor, which allows the control and monitoring of F372 to be carried out in a different part of your home to where it is located.

Part no 067 064

SOLAR PACKAGE NIBE PV

NIBE PV is a modular system comprising solar panels, assembly parts and inverters, which is used to produce your own electricity.

ACCESSORY BOARD AXC 20

Accessory board for hot water circulation, damper for frost protection and/or external heating medium pump.

Part no. 067 609

SUPPLY AIR MODULE SAM

SAM is a supply air module specially developed for houses with supply and exhaust air systems.

SAM 42

(approx. 28-70 l/s)

Part no. 067 759

WATER HEATER

Eminent

Water heater with immersion heater.

Eminent 35

Corrosion protection:

Copper Part no. 072 310

Enamel Part no. 072 300

Stainless Part no. 072 320

Eminent 55

Corrosion protection:

Copper Part no. 072 340

Enamel Part no. 072 330

Stainless Part no. 072 350

Eminent 100

Corrosion protection:

Copper Part no. 072 370

Enamel Part no. 072 360

Stainless Part no. 072 380

Eminent 120

Corrosion protection:

Stainless Part no. 072 384

Compact

Water heater with immersion heater.

Compact 100

Corrosion protection:

Copper Part no. 084 010

Compact 200

Corrosion protection:

Copper Part no. 084 020

Enamel Part no. 084 070

Stainless Part no. 084 050

Compact 300

Corrosion protection:

Copper Part no. 084 030

Enamel Part no. 084 080

Stainless Part no. 084 060

TOP CABINET TOC 30

Top cabinet, which conceals any pipes/ventilation ducts.

Height 245 mm

Part no. 067 517

Height 345 mm


Part no. 067 518

Height 385-635 mm

Part no. 067 519

Technical data

Dimensions



Technical specifications

| 3x400 V | | Stainless |
|--|---------|-----------------|
| Output data according to EN 14 511 | | |
| Heating capacity (P _H)/COP ¹ | kW/- | 2.18 / 3.93 |
| Heating capacity (P _H)/COP ² | kW/- | 2.03 / 3.24 |
| Heating capacity (P _H)/COP ³ | kW/- | 1.88 / 2.74 |
| Output data according to EN 14 825 | | |
| Rated heating output (P _{designh}) | kW | 3 |
| SCOP cold climate, 35°C / 55 °C | | 3.55 / 2.98 |
| SCOP average climate, 35 °C / 55 °C | | 3.35 / 2.83 |
| SCOP warm climate, 35°C / 55°C | | 3.23 / 2.73 |
| Additional power | | |
| Max power, immersion heater (factory setting) | kW | 10.3 (5.6) |
| Energy rating, average climate | | |
| The product's efficiency class room heating, average climate 35 / 55 °C ⁴ | | A+ / A+ |
| The system's efficiency class room heating, average climate 35 / 55 °C ⁵ | | A+ / A+ |
| Declared tap profile/efficiency class hot water heating ⁶ | | L / A |
| Electrical data | | |
| Rated voltage | V | 400 V 3N ~ 50Hz |
| Max operating current | A | 20.3 |
| Min. fuse rating | A | 10 |
| Drive output heating medium pump | W | 4-34 |
| Driving power exhaust air fan | W | 10-165 |
| Enclosure class | | IP 21 |
| Equipment Compliant with IEC 61000-3-12 | | |
| For Connection Design Purposes, Compliant with IEC 61000-3-3 technical requirements | | |
| Refrigerant circuit | | |
| Type of refrigerant | | R290 |
| GWP refrigerant | | 0.02 |
| Volume | kg | 0.4 |
| CO ₂ equivalent | ton | 0.000006 |
| Cut-out value pressostat HP | MPa/bar | 2.45 / 24.5 |
| Cut-out value pressostat LP | MPa/bar | 0.15 / 1.5 |
| Heating medium circuit | | |
| Opening pressure, safety valve | MPa/bar | 0.25 / 2.5 |
| Max temperature, supply line (factory setting) | °C | 70 (60) |
| Ventilation | | |
| Min. air flow at exhaust air temperature at least 20°C | l/s | 28 |
| Min. air flow at exhaust air temperature below 20°C | l/s | 31 |
| Noise | | |
| Sound effect level according to EN 12 102 (L _{w(A)}) ⁷ | dB(A) | 46.5-48.0 |
| Sound pressure level in the installation room (L _{P(A)}) ⁸ | dB(A) | 42.5-44.0 |
| Pipe connections | | |
| Heating medium ext Ø | mm | 22 |
| Hot water ext Ø | mm | 22 |
| Cold water ext Ø | mm | 22 |
| Docking ext Ø | mm | 22 |
| Ventilation Ø | mm | 125 |

¹ A20(12)W35, exhaust air flow 56 l/s (200 m³/h)

² A20(12)W45, exhaust air flow 42 l/s (150 m³/h)

³ A20(12)W55, exhaust air flow 31 l/s (110 m³/h)

⁴ Scale for the product's efficiency class room heating: A+++ to D.

⁵ Scale for the system's efficiency class room heating: A+++ to G. Reported efficiency for the system takes the product's temperature regulator into account.

⁶ Scale for efficiency class hot water: A+ to F.

⁷ The value varies with the selected fan curve. For more detailed sound data, including sound to channels, visit nibe.eu.

⁸ The value can vary with the room's damping capacity. These values apply at a damping of 4 dB.

| Other 3x400 V | | Stainless |
|---|---------|---------------|
| Water heater and heating section | | |
| Volume heating section | litre | 70 |
| Volume, hot water heater | litre | 170 |
| Max pressure in hot water heater | MPa/bar | 1.0 / 10.0 |
| Capacity, hot water | | |
| Tap volume 40°C according to EN 16 147($V_{max.}$) ¹ | litre | 217/248 |
| COP at Normal comfort (COP_p) | | 1.88 |
| Heat loss at Normal comfort (P_{es}) | W | 54 |
| Dimensions and weight | | |
| Width | mm | 600 |
| Depth | mm | 616 |
| Height incl. feet | | 2,100 - 2,125 |
| Required ceiling height | mm | 2,170 |
| Weight | kg | 195 |
| Part No. | | 066 268 |
| EPREL no. | | 217 92 79 |

¹ A20(12) exhaust air flow 42 l/s (150 m³/h). Comfort mode, normal/large

| 3x230 V | | Stainless |
|--|---------|------------------|
| Output data according to EN 14 511 | | |
| Heating capacity (P _H)/COP ¹ | kW/- | 2.18 / 3.93 |
| Heating capacity (P _H)/COP ² | kW/- | 2.03 / 3.24 |
| Heating capacity (P _H)/COP ³ | kW/- | 1.88 / 2.74 |
| Output data according to EN 14 825 | | |
| Rated heating output (P _{designh}) | kW | 3 |
| SCOP cold climate, 35°C / 55 °C | | 3.55 / 2.98 |
| SCOP average climate, 35 °C / 55 °C | | 3.35 / 2.83 |
| SCOP warm climate, 35°C / 55°C | | 3.23 / 2.73 |
| Additional power | | |
| Max power, immersion heater (factory setting) | kW | 10.0 (6.67) |
| Energy rating, average climate | | |
| The product's efficiency class room heating, average climate 35 / 55 °C ⁴ | | A+ / A+ |
| The system's efficiency class room heating, average climate 35 / 55 °C ⁵ | | A+ / A+ |
| Declared tap profile/efficiency class hot water heating ⁶ | | L / A |
| Electrical data | | |
| Rated voltage | V | 230 V 3N - 50 Hz |
| Max operating current | A | 31.1 |
| Min. fuse rating | A | 10 |
| Drive output heating medium pump | W | 4-34 |
| Driving power exhaust air fan | W | 10-165 |
| Enclosure class | | IP 21 |
| Equipment Compliant with IEC 61000-3-12 | | |
| For Connection Design Purposes, Compliant with IEC 61000-3-3 technical requirements | | |
| Refrigerant circuit | | |
| Type of refrigerant | | R290 |
| GWP refrigerant | | 0.02 |
| Volume | kg | 0.4 |
| CO ₂ equivalent | ton | 0.000006 |
| Cut-out value pressostat HP | MPa/bar | 2.45 / 24.5 |
| Cut-out value pressostat LP | MPa/bar | 0.15 / 1.5 |
| Heating medium circuit | | |
| Opening pressure, safety valve | MPa/bar | 0.25 / 2.5 |
| Max temperature, supply line (factory setting) | °C | 70 (60) |
| Ventilation | | |
| Min. air flow at exhaust air temperature at least 20°C | l/s | 28 |
| Min. air flow at exhaust air temperature below 20°C | l/s | 31 |
| Noise | | |
| Sound effect level according to EN 12 102 (L _{W(A)}) ⁷ | dB(A) | 46.5-48.0 |
| Sound pressure level in the installation room (L _{P(A)}) ⁸ | dB(A) | 42.5-44.0 |
| Pipe connections | | |
| Heating medium ext Ø | mm | 22 |
| Hot water ext Ø | mm | 22 |
| Cold water ext Ø | mm | 22 |
| Docking ext Ø | mm | 22 |
| Ventilation Ø | mm | 125 |

¹ A20(12)W35, exhaust air flow 56 l/s (200 m³/h)

² A20(12)W45, exhaust air flow 42 l/s (150 m³/h)

³ A20(12)W55, exhaust air flow 31 l/s (110 m³/h)

⁴ Scale for the product's efficiency class room heating: A+++ to D.

⁵ Scale for the system's efficiency class room heating: A+++ to G. Reported efficiency for the system takes the product's temperature regulator into account.

⁶ Scale for efficiency class hot water: A+ to F.

⁷ The value varies with the selected fan curve. For more detailed sound data, including sound to channels, visit nibe.eu.

⁸ The value can vary with the room's damping capacity. These values apply at a damping of 4 dB.

| Other 3x230 V | | Stainless |
|---|---------|---------------|
| Water heater and heating section | | |
| Volume heating section | litre | 70 |
| Volume, hot water heater | litre | 170 |
| Max pressure in hot water heater | MPa/bar | 1.0 / 10.0 |
| Capacity, hot water | | |
| Tap volume 40°C according to EN 16 147($V_{max.}$) ¹ | litre | 217/248 |
| COP at Normal comfort (COP_p) | | 1.88 |
| Heat loss at Normal comfort (P_{es}) | W | 54 |
| Dimensions and weight | | |
| Width | mm | 600 |
| Depth | mm | 616 |
| Height incl. feet | | 2,100 - 2,125 |
| Required ceiling height | mm | 2,170 |
| Weight | kg | 199 |
| Part No. | | 066 266 |
| EPREL no. | | 217 92 76 |

¹ A20(12) exhaust air flow 42 l/s (150 m³/h). Comfort mode, normal/large

Energy labelling

INFORMATION SHEET

| Supplier | | NIBE |
|---|-----|-------------|
| Model | | F372 |
| Temperature application | °C | 35 / 55 |
| Declared load profile for water heating | | L |
| Seasonal space heating energy efficiency class, average climate | | A+ / A+ |
| Water heating energy efficiency class, average climate | | A |
| Rated heat output ($P_{designh}$), average climate | kW | 3 / 3 |
| Annual energy consumption space heating, average climate | kWh | 1598 / 1898 |
| Annual energy consumption water heating, average climate | kWh | 1361 |
| Seasonal space heating energy efficiency, average climate | % | 131 / 110 |
| Water heating energy efficiency, average climate | % | 75 |
| Sound power level L_{WA} indoors | dB | 47 |
| Rated heat output ($P_{designh}$), cold climate | kW | 3 / 3 |
| Rated heat output ($P_{designh}$), warm climate | kW | 3 / 3 |
| Annual energy consumption space heating, cold climate | kWh | 1808 / 2162 |
| Annual energy consumption water heating, cold climate | kWh | 1361 |
| Annual energy consumption space heating, warm climate | kWh | 1081 / 1276 |
| Annual energy consumption water heating, warm climate | kWh | 1361 |
| Seasonal space heating energy efficiency, cold climate | % | 139 / 116 |
| Water heating energy efficiency, cold climate | % | 75 |
| Seasonal space heating energy efficiency, warm climate | % | 126 / 106 |
| Water heating energy efficiency, warm climate | % | 75 |
| Sound power level L_{WA} outdoors | dB | - / - |

Compressor motor is exempted from EU 2019/1781 due to that motors completely integrated into compressor and energy performance cannot be tested independently from the product.

DATA FOR ENERGY EFFICIENCY OF THE PACKAGE

| Model | | F372 |
|--|----|----------------|
| Temperature application | °C | 35 / 55 |
| Controller, class | | VII |
| Controller, contribution to efficiency | % | 3.5 |
| Seasonal space heating energy efficiency of the package, average climate | % | 135 / 114 |
| Seasonal space heating energy efficiency class of the package, average climate | | A+ / A+ |
| Seasonal space heating energy efficiency of the package, cold climate | % | 142 / 119 |
| Seasonal space heating energy efficiency of the package, warm climate | % | 129 / 109 |


Reported efficiency for the system also takes the temperature regulator into account. If the system is supplemented with external additional heat or solar heating, the total efficiency of the system must be recalculated.

TECHNICAL DOCUMENTATION

| Model | | | | F372 | | | |
|---|---|------------|-----|---|--------------------|------|-------------------|
| Type of heat pump | <input type="checkbox"/> Air-water <input checked="" type="checkbox"/> Exhaust-water <input type="checkbox"/> Brine-water <input type="checkbox"/> Water-water | | | | | | |
| Low-temperature heat pump | <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No | | | | | | |
| Integrated immersion heater for additional heat | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | | | | | | |
| Heat pump combination heater | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No | | | | | | |
| Climate | <input checked="" type="checkbox"/> Average <input type="checkbox"/> Cold <input type="checkbox"/> Warm | | | | | | |
| Temperature application | <input checked="" type="checkbox"/> Medium (55°C) <input type="checkbox"/> Low (35°C) | | | | | | |
| Applied standards | EN14825, EN16147 | | | | | | |
| Rated heat output | Prated | 2,6 | kW | Seasonal space heating energy efficiency | η_s | 110 | % |
| Declared capacity for space heating at part load and at outdoor temperature T_j | | | | Declared coefficient of performance for space heating at part load and at outdoor temperature T_j | | | |
| $T_j = -7\text{ °C}$ | Pdh | 1.7 | kW | $T_j = -7\text{ °C}$ | COPd | 2.72 | - |
| $T_j = +2\text{ °C}$ | Pdh | 1.7 | kW | $T_j = +2\text{ °C}$ | COPd | 3.22 | - |
| $T_j = +7\text{ °C}$ | Pdh | 1.7 | kW | $T_j = +7\text{ °C}$ | COPd | 3.37 | - |
| $T_j = +12\text{ °C}$ | Pdh | 1.7 | kW | $T_j = +12\text{ °C}$ | COPd | 3.28 | - |
| $T_j = \text{biv}$ | Pdh | 1.7 | kW | $T_j = \text{biv}$ | COPd | 3.04 | - |
| $T_j = \text{TOL}$ | Pdh | 1.7 | kW | $T_j = \text{TOL}$ | COPd | 2.56 | - |
| $T_j = -15\text{ °C}$ (if TOL < -20 °C) | Pdh | | kW | $T_j = -15\text{ °C}$ (if TOL < -20 °C) | COPd | | - |
| Bivalent temperature | T_{biv} | -1.6 | °C | Min. outdoor air temperature | TOL | -10 | °C |
| Cycling interval capacity | P _{cy} | | kW | Cycling interval efficiency | COP _{cy} | | - |
| Degradation coefficient | Cdh | 0.96 | - | Max supply temperature | WTOL | 58 | °C |
| <i>Power consumption in modes other than active mode</i> | | | | <i>Additional heat</i> | | | |
| Off mode | P _{OFF} | 0.002 | kW | Rated heat output | P _{sup} | 0.9 | kW |
| Thermostat-off mode | P _{TO} | 0.02 | kW | | | | |
| Standby mode | P _{SB} | 0.015 | kW | Type of energy input | Electric | | |
| Crankcase heater mode | P _{CK} | 0.024 | kW | | | | |
| <i>Other items</i> | | | | | | | |
| Capacity control | Fixed | | | Rated airflow (air-water) | | 150 | m ³ /h |
| Sound power level, indoors/outdoors | L _{WA} | 47 / - / - | dB | Nominal heating medium flow | | 0.18 | m ³ /h |
| Annual energy consumption | Q _{HE} | 1,898 | kWh | Brine flow brine-water or water-water heat pumps | | | m ³ /h |
| <i>For heat pump combination heater</i> | | | | | | | |
| Declared load profile for water heating | L | | | Water heating energy efficiency | η_{wh} | 75 | % |
| Daily energy consumption | Q _{elec} | 6.20 | kWh | Daily fuel consumption | Q _{fuel} | | kWh |
| Annual energy consumption | AEC | 1,361 | kWh | Annual fuel consumption | AFC | | GJ |
| Contact information | NIBE Energy Systems - Box 14 - Hannabadsvägen 5 - 285 21 Markaryd - Sweden | | | | | | |

Electrical circuit diagram


3X400 V



| | | | |
|--------------------------------|-----------------|------------------------|-------------------|
| Material Quality/Specification | | Mass (kg) | |
| Revision note | Rev. Checked by | Rev. Date (YYYY-MM-DD) | |
| Dimension | Revised by | Checked by | Date (YYYY-MM-DD) |
| 400V 3N~50Hz, 9.25/10.25 kW | Designer | Status | |
| NIBE | | | |
| NIBE AB MARKARYD SWEDEN | | | |
| WIRING DIAGRAM F372 | | Plant | Formal Sheet |
| ELSCHEMA F372 | | Location | Next Sheet |
| POW | | | 1 |
| | | Drawing no | Rev |
| | | 051322 | 1 |

1 2 3 4 5 6 7 8

| COLOR CODE | |
|------------------|--------|
| UL/CSA DIN 47700 | White |
| Black | White |
| Brown | Brown |
| Red | Green |
| Orange | Yellow |
| Yellow | Grey |
| Green | Pink |
| Blue | Blue |
| Violet | Red |
| Grey | Black |
| White | Violet |



Dimension: 400V 3N~ 50Hz, 9.25/10.25 kW
 Revision note

Material Quality/Specification

| | | | |
|----------|----------------|-----------------------|-----------|
| Rev by | Rev Checked by | Rev date (YYYY-MM-DD) | Mass (kg) |
| Designer | Checked by | Date (YYYY-MM-DD) | |

Status


NIBE
 NIBE AB
 MARKARYD
 SWEDEN

WIRING DIAGRAM F372
 ELSICHEMA F372
 BASE

| | | | |
|------------|--------|------------|-------|
| Plant | Formal | Next sheet | Sheet |
| Location | A3 | 3 | 2 |
| Drawing no | 051322 | | |
| Rev | 1 | | |

1 2 3 4 5 6 7 8


A B C D E F



| Material Quality/Specification | | Mass (kg) | |
|--------------------------------|------------------------------|------------|-------------------|
| Dimension | 400V 3N~ 50Hz, 9.25/10.25 kW | Rev by | Rev Checked by |
| Revision note | | Designer | Date (YYYY-MM-DD) |
| Status | | Checked by | Plant |
| NIBE | | Formal | Next sheet |
| NIBE AB | | A3 | 4 |
| MARKARYD | | Location | Drawing no |
| SWEDEN | | | 051322 |
| | | Rev | 1 |

1 2 3 4 5 6 7 8

| COLOR CODE | |
|------------------|--------|
| UL/CSA DIN 47700 | |
| Black | White |
| Brown | Brown |
| Red | Green |
| Orange | Yellow |
| Yellow | Grey |
| Green | Pink |
| Blue | Blue |
| Violet | Red |
| Grey | Black |
| White | Violet |




Dimension: 400V 3N~ 50Hz, 9.25/10.25 KW
 Revision note

NIBE
 NIBE AB
 MARKARYD
 SWEDEN

WIRING DIAGRAM F372
 ELSCHEMA F372
 BASE

| | | | | | |
|----------|-----------------------|------------|-------------------|------------------------|---------------|
| Material | Quality/Specification | Rev. by | Rev. Checked by | Rev. date (YYYY-MM-DD) | Mass (kg) |
| Status | Designer | Checked by | Date (YYYY-MM-DD) | Plant | Formal |
| | | | | A3 | Next sheet: 5 |
| | | | | Location | Drawing no |
| | | | | | 051322 |
| | | | | Rev | 1 |



-AA4
PCA Display Unit

SELV

| | | | |
|---------------|--------------------------------|-----------------|-----------------------|
| Dimension | Material Quality/Specification | | Mass (kg) |
| Revision note | 400V 3N~ 50Hz, 9.25/10.25 kW | Rev. Checked by | Rev date (YYYY-MM-DD) |
| | | Designer | Checked by |
| | | Status | Date (YYYY-MM-DD) |
| | | Plant | Formal |
| | | Location | Next sheet: Sheet: |
| | | | Drawing no |
| | | | Rev |




WIRING DIAGRAM F372
ELSCHEMA F372
DISPLAY

NIBE AB
MARKARYD
SWEDEN

051322 1

1 2 3 4 5 6 7 8


A B C D E F



| | | | |
|-----------------------------------|---------------------|---------------------|------------------------|
| Material Quality/Specification | | Mass (kg) | |
| Dimension | 230V 3~ 50Hz, 10 kW | Rev. Checked by | Rev. date (YYYY-MM-DD) |
| Revision note | | Checked by | Date (YYYY-MM-DD) |
| NIBE AB MARKARYD SWEDEN | Status | Plant | Formal |
| | | WIRING DIAGRAM F372 | A3 |
| | | ELSCHEMA F372 | 2 |
| | | POWER | 1 |
| | | Location | Drawing no |
| | | | 051323 |
| | | | Rev |
| | | | 1 |

1 2 3 4 5 6 7 8


| COLOR CODE | |
|------------------|--------|
| IL/CSA DIN 47700 | White |
| Black | White |
| Brown | Brown |
| Red | Green |
| Orange | Yellow |
| Yellow | Grey |
| Green | Pink |
| Blue | Blue |
| Violet | Red |
| Grey | Black |
| White | Violet |



| | | | | | | | |
|--|--|--|----------------|-----------------------|-------------------|-------------|--------|
| Dimension | | Material Quality/Specification | | Mass (kg) | | | |
| 230V 3~ 50Hz, 10 kW | | | | | | | |
| Revision note | | Rev by | Rev Checked by | Rev date (YYYY-MM-DD) | | | |
| | | Status | Designer | Checked by | Date (YYYY-MM-DD) | | |
| NIBE AB MARKARYD SWEDEN | | WIRING DIAGRAM F372 ELSCHEMA F372 BASE | | | Plant | Formal | |
| | | | | | Location | Next sheet: | Sheet: |
| | | | | | Drawing no | 051323 | 1 |

1 2 3 4 5 6 7 8


A B C D E F



| Material Quality/Specification | | Mass (kg) | |
|--------------------------------|----------------|-----------------------|-------------------|
| Rev by | Rev Checked by | Rev date (YYYY-MM-DD) | |
| | | | |
| Status | | Checked by | Date (YYYY-MM-DD) |
| NIBE | | Plant | Formal |
| NIBE AB | | MARKARYD | A3 |
| SWEDEN | | Location | Sheet |
| WIRING DIAGRAM F372 | | | 4 |
| ELSICHEMA F372 | | Drawing no | 051323 |
| BASE | | Rev | 1 |

1 2 3 4 5 6 7 8


| COLOR CODE | |
|------------------|--------|
| UL/CSA DIN 47700 | |
| Black | White |
| Brown | Brown |
| Red | Green |
| Orange | Yellow |
| Yellow | Grey |
| Green | Pink |
| Blue | Blue |
| Violet | Red |
| Grey | Black |
| White | Violet |



| | | | |
|---------------------|--------------------------------|----------------|-----------------------|
| Dimension | Material Quality/Specification | | Mass (kg) |
| 230V 3~ 50Hz, 10 kW | Rev by | Rev Checked by | Rev date (YYYY-MM-DD) |
| Revision note | Status | Designer | Date (YYYY-MM-DD) |
| | Plant | | Formal |
| | MARKARYD | | A3 |
| | SWEDEN | | Sheet |
| WIRING DIAGRAM F372 | | Location | 5 |
| ELSCHEMA F372 | | Drawing no | 4 |
| BASE | | Rev | 051323 1 |

1 2 3 4 5 6 7 8

A B C D E F




SELV

| | | | |
|--|---------------------|-----------------|-----------------------|
| Material Quality/Specification | | Mass (kg) | |
| Dimension | 230V 3~ 50Hz, 10 kW | Rev by | Rev date (YYYY-MM-DD) |
| Revision note | | Designer | Checked by |
| NIBE AB MARKARYD SWEDEN | | Status | Date (YYYY-MM-DD) |
| | | Plant | Formal |
| WIRING DIAGRAM F372 | | Location | Next sheet: 6 |
| ELSHEMA F372 | | Drawing no | Rev |
| INPUT | | 051323 1 | |

1 2 3 4 5 6 7 8

-AA4
PCA Display Unit



SELV

| | | | |
|-----------------------------------|---------------------|-------------------|-----------------------|
| Material Quality/Specification | | Mass (kg) | |
| Dimension | 230V 3~ 50Hz, 10 kW | Rev. Checked by | Rev date (YYYY-MM-DD) |
| Revision note | | Designer | Checked by |
| Status | | Date (YYYY-MM-DD) | |
| NIBE AB MARKARYD SWEDEN | Plant | Formal | Next sheet: Sheet: |
| | WIRING DIAGRAM F372 | A3 | - |
| | ELSCHEMA F372 | Location | Drawing no |
| DISPLAY | | | Rev |
| | | | 051323 |
| | | | 1 |

Item register

A

Accessibility, electrical connection, 22
Accessories, 55
Alarm, 53
Assembly, 11

B

Back button, 39

C

Cable lock, 23
Climate system, 19
Cold and hot water
 Connecting cold and hot water, 19
Commissioning and adjusting, 30
 Filling and venting, 30
 Preparations, 30
 Start guide, 31
 Start-up and inspection, 31
Connecting accessories, 29
Connecting cold and hot water, 19
Connecting current sensors, 27
Connecting external operating voltage for the control system, 24
Connecting hot water circulation, 20
Connecting the climate system, 19
Connections, 24
Control, 39, 43
 Control - Introduction, 39
 Control - Menus, 43
Control - Introduction, 39
 Display unit, 39
 Menu system, 39
Control knob, 39
Control - Menus, 43
 Menu 5 - SERVICE, 45

D

Delivery and handling, 11
 Assembly, 11
 Installation area, 11
 Removing parts of the insulation, 13
 Removing the covers, 12
 Supplied components, 12
 Transport, 11
Dimensions and pipe connections, 18
Dimensions and setting-out coordinates, 56
Display, 39
Display unit, 39
 Back button, 39
 Control knob, 39
 Display, 39
 OK button, 39
 Status lamp, 39
 Switch, 39
Disturbances in comfort, 53
 Alarm, 53
 Manage alarm, 53
 Troubleshooting, 53
Docking alternatives
 Two or more climate systems, 20
Draining the climate system, 49
Draining the hot water heater, 49

E

Electrical addition - maximum output, 26
Electrical circuit diagram, 63
 3x230V, 69
Electrical connections, 22
 Accessibility, electrical connection, 22
 Cable lock, 23
 Connecting accessories, 29
 Connecting external operating voltage for the control system, 24
 Connections, 24
 Electrical addition - maximum output, 26
 External connection options, 27
 Load monitor, 26
 Miniature circuit-breaker, 22
 myUplink, 27
 Optional connections, 26
 Outdoor sensor, 25
 Power connection, 24
 Removing the cover, base board, 23
 Removing the cover, immersion heater circuit board, 23
 Removing the hatch, input circuit board, 23
 Room sensor, 25
 Settings, 26
 Standby mode, 26
 Temperature limiter, 22
Electrical wiring diagram
 3x400V, enamel and stainless steel, 63
Energy labelling, 61
 Data for energy efficiency of the package, 61
 Information sheet, 61
 Technical documentation, 62
Exhaust air duct, 21
External connection options, 27
 Possible selection for AUX inputs, 28

F

Filling and venting, 30
 Filling the climate system, 30
 Filling the hot water heater, 30
 Venting the climate system, 30
Filling the climate system, 30
Filling the hot water heater, 30

H

Handling, 4
Helping the circulation pump to start, 49
Help menu, 42

I

Important information, 4
 Recovery, 9
Inspection of the installation, 10
Installation alternative
 Connecting hot water circulation, 20
 Water heater with immersion heater, 19
Installation area, 11

M

Manage alarm, 53
Marking, 4
Menu 5 - SERVICE, 45
Menu system, 39
 Help menu, 42
 Operation, 41

- Scroll through the windows, 42
- Selecting menu, 41
- Selecting options, 41
- Setting a value, 41
- Use the virtual keyboard, 42
- Miniature circuit-breaker, 22
- myUplink, 27
- O**
- OK button, 39
- Operation, 41
- Optional connections, 26
- Outdoor sensor, 25
- P**
- Pipe and ventilation connections, 17
 - Climate system, 19
 - Cold and hot water
 - Connecting cold and hot water, 19
 - Connecting the climate system, 19
 - Dimensions and pipe connections, 18
 - Exhaust air duct, 21
 - General pipe connections, 17
 - Maximum boiler and radiator volumes, 17
 - Pipe dimensions, 18
 - Setting out dimensions, 18
 - Symbol key, 19
- Pipe dimensions, 18
- Possible selection for AUX inputs, 28
- Power connection, 24
- Preparations, 30
- R**
- Remove parts of the insulation, 13
- Removing the cover, base board, 23
- Removing the cover, immersion heater circuit board, 23
- Removing the covers, 12
- Removing the hatch, input circuit board, 23
- Room sensor, 25
- S**
- Safety information
 - Handling, 4
 - Inspection of the installation, 10
 - Marking, 4
 - Safety precautions, 5
 - Serial number, 9
 - Symbols, 4
- Safety precautions, 5
 - Collection, 8
 - Decommissioning, 8
 - Filling, 7
 - Leak testing, 6
 - Marking, 8
 - Removal and draining, 7
 - Repairing sealed components, 6
 - When working in the refrigerant circuit, 9
 - Wiring, 6
- Scroll through the windows, 42
- Selecting menu, 41
- Selecting options, 41
- Serial number, 9
- Service, 49
 - Service actions, 49
- Service actions, 49
 - Draining the climate system, 49
 - Draining the hot water heater, 49
 - Helping the circulation pump to start, 49
 - Standby mode, 49
 - Temperature sensor data, 50
- USB service outlet, 50
- Setting a value, 41
- Setting out dimensions, 18
- Settings, 26
- Standby mode, 49
 - Power in emergency mode, 26
- Start guide, 31
- Start-up and inspection, 31
 - Commissioning without fan , 32
 - Setting the pump speed, 33
 - Setting the ventilation, 32
- Status lamp, 39
- Supplied components, 12
- Switch, 39
- Symbol key, 19
- Symbols, 4
- T**
- Technical data, 56
 - Dimensions and setting-out coordinates, 56
 - Electrical circuit diagram, 63
 - Technical Data, 57
- Technical Data, 57
- Temperature limiter, 22
 - Resetting, 22
- Temperature sensor data, 50
- The heat pump design, 14
- Transport, 11
- Troubleshooting, 53
- U**
- USB service outlet, 50
- Use the virtual keyboard, 42
- V**
- Venting the climate system, 30

Contact information

AUSTRIA

KNV Energietechnik GmbH
Gahberggasse 11, 4861 Schörfling
Tel: +43 (0)7662 8963-0
mail@knv.at
knv.at

FINLAND

NIBE Energy Systems Oy
Juurakkotie 3, 01510 Vantaa
Tel: +358 (0)9 274 6970
info@nibe.fi
nibe.fi

GREAT BRITAIN

NIBE Energy Systems Ltd
3C Broom Business Park,
Bridge Way, S41 9QG Chesterfield
Tel: +44 (0)330 311 2201
info@nibe.co.uk
nibe.co.uk

POLAND

NIBE-BIAWAR Sp. z o.o.
Al. Jana Pawla II 57, 15-703 Białystok
Tel: +48 (0)85 66 28 490
biawar.com.pl

CZECH REPUBLIC

Družstevní závody Dražice - strojírna
s.r.o.
Dražice 69, 29471 Benátky n. Jiz.
Tel: +420 326 373 801
nibe@nibe.cz
nibe.cz

FRANCE

NIBE Energy Systems France SAS
Zone industrielle RD 28
Rue du Pou du Ciel, 01600 Reyrieux
Tél: 04 74 00 92 92
info@nibe.fr
nibe.fr

NETHERLANDS

NIBE Energietechnik B.V.
Energieweg 31, 4906 CG Oosterhout
Tel: +31 (0)168 47 77 22
info@nibenl.nl
nibenl.nl

SWEDEN

NIBE Energy Systems
Box 14
Hannabadsvägen 5, 285 21 Markaryd
Tel: +46 (0)433-27 30 00
info@nibe.se
nibe.se

DENMARK

Vølund Varmeteknik A/S
Industrivej Nord 7B, 7400 Herning
Tel: +45 97 17 20 33
info@volundvt.dk
volundvt.dk

GERMANY

NIBE Systemtechnik GmbH
Am Reiherpfahl 3, 29223 Celle
Tel: +49 (0)5141 75 46 -0
info@nibe.de
nibe.de

NORWAY

ABK-Qviller AS
Brobekkeveien 80, 0582 Oslo
Tel: (+47) 23 17 05 20
post@abkqviller.no
nibe.no

SWITZERLAND

NIBE Wärmetechnik c/o ait Schweiz AG
Industriepark, CH-6246 Altishofen
Tel. +41 (0)58 252 21 00
info@nibe.ch
nibe.ch

For countries not mentioned in this list, contact NIBE Sweden or check nibe.eu for more information.

NIBE Energy Systems
Hannabadsvägen 5
Box 14
SE-285 21 Markaryd
info@nibe.se
nibe.eu

IHB EN 2444-2 831617

This is a publication from NIBE Energy Systems. All product illustrations, facts and data are based on the available information at the time of the publication's approval.

NIBE Energy Systems makes reservations for any factual or printing errors in this publication.

©2024 NIBE ENERGY SYSTEMS

