


# Spare parts list

NIBE MT-MB21



Pump	Control valve
18	19 20

Spare parts list	
Pos.	Description
1	Compressor
2	PCB board incl. cable harness
3	Sensor, thermo
4	Heating element
5	Anode
6	Adjustable foot 3 pcs.
7	Evaporator, insulated
8	Tube kit, incl. HP switch
9	Safety breakers 2 pcs.
10	Front panel - Light grey
11	Display with frame
12	Top shell - white
13	Top cover - white
14	Insulation panel
15	*3-way valve
16	*3-way valve actuator
17	O-ring set 10 pcs. incl. 2 clips + 2 gaskets
18	**Pump
19	***Control valve
20	***Actuator for control valve

\* : Preheat versions only  
 \*\* : Pump versions only  
 \*\*\*: Control valve versions only



# Spare parts list

## NIBE MT-MB21

Item	NIBE art. no.	Description
1	219667	Compressor
2	818083	PCB board incl. cable harness
3	409389	Sensor, thermo
4	319001	Heating element
5	724047	Anode
6	437008	Adjustable foot, 3 pcs
7	724054	Heat exchanger, insulated
8	724055	Refrigerant tube set, incl. HP switch
9	718943	Safety breakers 2 pcs
10	436001	Front panel
11	818084	Display with frame
12	434889	Top Shell
13	434889	Top cover
14	434890	Insulation panel
15	524711	*3-way valve
16	524712	*3-way valve actuator
17	416231	O-ring set 10 pcs. incl 2 clips + 2 gaskets
18	524713	**Pump
19	724056	***Control calve
20	724057	***Actuator for control valve

\* : Preheat versions only

\*\* : Pump versions only

\*\*\*: Control valve versions only